



Yields 2
heaping cups
Food grade
silicone
Dishwasher safe

Micro-Pop[™]
Mini Silicone
Popcorn
Popper
For Microwave Use

2 CUP

USE INSTRUCTIONS
READ WARNINGS and all instructions
before first use!

- 1** Expand popper from collapsed position to full upright position.
- 2** Remove lid and add 1 heaping Tbsp of fresh popcorn kernels into silicone bowl.
- 3** Place lid on top of the popper.
- 4** Not all microwaves work the same, so play with the timing until you get it just right. Try setting the microwave between 1:30-2:00 minutes and listen to the pops. Do not use popcorn button or setting on your microwave. It may take a while for things to get poppin'. Be patient and do not leave microwave unattended. Experiment a little - your microwave may cook the popcorn faster or slower than the 1:30-2:00 average! When the popping slows down to about 2 seconds apart, stop the microwave to prevent burning. If no popping occurs within 90 seconds, turn OFF microwave. Do not stop the microwave and start it again during the same batch.



RECIPES

NACHO CHEESE
2 tablespoons nutritional yeast
teaspoon garlic powder
teaspoon onion powder
teaspoon cumin
teaspoon nacho chili powder
Pinch cayenne powder (optional for extra spicy)
1 teaspoon sea salt

In a separate bowl, mix all ingredients together. Sprinkle desired amount on warm, freshly popped popcorn and toss to coat. Enjoy!
Store leftover seasoning in airtight container.

KETTLE CORN
 $\frac{1}{8}$ cup granulated sugar
 $\frac{1}{8}$ cup packed light brown sugar
tablespoon kosher salt

In a separate bowl, mix all ingredients together. Sprinkle desired amount on warm, freshly popped popcorn and toss to coat. Enjoy!
Store leftover seasoning in airtight container.

Tips: Love it? Double or triple the recipe and save for next time! Store in airtight container.

WARNING: Silicone cools slowly, always use an oven mitt when removing popper from microwave.

WARNING: Remove lid safely from popper using handle on lid with an oven mitt.

WARNING: Hold hot popper away from your face and body.

WARNING: Never microwave an empty popcorn popper. Damage to your microwave oven may result.

WARNING: If no popping occurs within 90 seconds, turn OFF microwave.

WARNING: Never leave microwave unattended while in use.

IMPORTANT SAFETY INFORMATION

Read before use:

- Wash product thoroughly before first use.
- Always use popper in expanded position. Never use in collapsed position.
- Always use an oven mitt.
- After heating, popper and lid will be hot. Escaping steam from lid can cause burns. When removing the lid or handling the popper always use a potholder or an oven mitt.
- Allow popper, lid and microwave to cool between batches.
- Clean popper and lid between batches.
- Easy to clean, popper and lid are both dishwasher safe, top rack only.
- Store popper in collapsed position after cleaning, be sure popper is completely dry.
- Keep out of reach of children.
- For microwave use only. Not for use on stovetop or any other source of heat.
- NEVER MICROWAVE AN EMPTY POPCORN POPPER.** Damage to your oven may result.
- Do not use popcorn button or setting on your microwave.
- Only use popcorn popper in a clean, fully functioning microwave oven and in accordance with all safety instructions in your microwave oven's instruction manual.
- Never use popcorn popper in a microwave oven with missing, improperly functioning, or restricted turntable and turntable support. Damage to your microwave oven may result. The turntable must be in place and unrestricted so it can rotate.

- It is very important to use fresh kernels that have not dried out and to store them in an airtight container to maintain their moisture. Popcorn kernels do not last indefinitely. Do not refrigerate kernels as this can dry them out. Do not use kernels past the manufacturer's expiration date.
- WARNING! Dried out kernels can cause damage to your microwave and in extreme cases, even cause fires.** Based on our kitchen tested time of 2 minutes, (average for most microwaves), popping should begin in 60-90 seconds. Understand your microwave by running a few tests with fresh kernels to establish the amount of time your microwave needs to pop the kernels optimally. Pay attention to the amount of time it takes for kernels to begin to pop. Use this as a guideline for future uses to avoid burning.

IF KERNELS HAVE NOT STARTED TO POP WITHIN 90 SECONDS STOP THE OVEN, DISCARD THE KERNELS AND OBTAIN NEW, FRESH KERNELS.

HOW MICROWAVES WORK

Microwave ovens heat by producing electromagnetic waves that cause water molecules in food to vibrate. This vibration produces heat. Microwaves do not "see" silicone or plastic. Never place the popper in the microwave oven empty. Damage to your oven can occur.

TIPS to getting your popcorn just right:

Not yielding perfect popcorn? Although our instructions are kitchen tested, microwave ovens can greatly vary.

- Always use fresh popcorn kernels. Store your popcorn in an airtight container. Refrigeration is not recommended.
- Not all microwaves are created equal. Microwaves will vary in wattage, and though many microwaves will pop your kernels just fine, there is always the few that want to be stubborn. If your precious popcorn is getting burnt when adding butter prior to popping, try adding the butter after all those kernels have transformed into beautiful puffed popcorn. Use a small, microwave-safe bowl to melt the butter and then use an oven mitt to pour it over your popcorn.
- Stopping and starting your microwave during the cooking cycle is not recommended. Once you stop the microwave, the steam buildup in the center of the kernel, which causes the popcorn to pop, will cool off and never reach the desired temperature to re-pop. If you restart the microwave you also risk burning the already popped popcorn. Using the sound test is the best way to determine if your popcorn is done. If there are more than two full seconds between pops, it's time to stop.