



Go to tsicustomerservice.com for product warranty registration

OPERATING INSTRUCTIONS

FUNCTION	ICON	DESCRIPTION
Power Switch		1. This switch turns on and off the main power. 2. The switch will be illuminated when the heater is on. 3. This switch needs to be on to use the heater and/or flame effect.
Flame Brightness Dimmer		1. Turning the dial clockwise will increase the brightness of the flame effect. 2. Turning the dial counter clockwise will decrease the brightness of the flame effect.
Thermostat Dial		1. Set the thermostat by turning the knob clockwise to allow the heater to warm up the room. 2. When the desired comfort level is reached, lower the thermostat by turning the knob counter clockwise until the unit shuts off.
Heater Switch		1. The 1500W switch will turn on the heater to the heat setting and will also turn the heater off.




Control Panel Location




Control Panel

BULB REPLACEMENT


1. Unplug the stove. Remove the screws holding the stove back panel in place. Remove the back panel to access the light bulb.



2. Unscrew 3 screws holding the baffle and remove it carefully.



3. Secure the back panel with 6 screws.



Manufactured and distributed by Twin-Star International, Inc., under license from Durafame, Inc. durafame, the flame symbol and logo are registered trademarks of Durafame, Inc.

PRODUCT SPECIFICATIONS

VOLTAGE	120 VAC, 60 Hz
AMPS	12.5 Amps
WATTS	1500 Watts

For Customer Service:

tsicustomerservice.com
1-888-674-7517
 8:30 a.m. - 5:30 p.m., EST, Monday - Friday

Note: When first running the heater there may be an odor. This is normal as the heater has a surface coating on the internal parts. For the first several hours of operation, the coating reacts with the internal parts to permanently protect them. The odor is safe; if you are sensitive to the odor, it is recommended to run the heater in a well-ventilated area until the odor dissipates.

Warning: This is an unvented, electric appliance. DO NOT attempt to burn wood or manufactured firelogs in or on this appliance or grate.

IMPORTANT INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electrical shock, injury to persons, and hyperthermia, including the following:

1. Read all instructions before using this appliance.
2. This appliance is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this appliance. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes and curtains at least 3 feet (0.9 m) from the front of this appliance. **WARNING:** In order to avoid overheating, do not cover the heater.
3. Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
4. Always unplug heater when not in use.
5. Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Discard heater, or return to authorized service facility for examination and/or repair.
6. Do not use outdoors.
7. This appliance is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
8. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
9. To disconnect this appliance, turn controls to the off position, then remove plug from outlet.
10. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the appliance.
11. To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where opening may become blocked.
12. This appliance has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
13. Use this appliance only as described in the manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons.
14. This product is equipped with a polarized plug (one blade is wider than the other blade). To reduce the risk of electrical shock, this plug will fit into a polarized outlet only one way. This is a safety feature. If you are unable to insert the plug into the electrical outlet, try reversing the plug. If the plug still does not fit, contact a qualified electrician. Always plug heaters directly into a wall outlet/ receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
15. Hyperthermia can result in death. Symptoms of hyperthermia include high body temperature, headache, nausea, vomiting, tiredness, dizziness, fainting, and rapid pulse. If you begin to experience symptoms related to hyperthermia, turn off the heater and seek medical attention.
16. To avoid excessive room temperatures which can cause hyperthermia: DO NOT leave product running unattended in a confined space around infants, or individuals with reduced physical, sensory, or mental capabilities.



SAVE THESE INSTRUCTIONS

1-YEAR LIMITED WARRANTY

The manufacturer warrants that your new Electric Stove is free from manufacturing and material defects for a period of one year from date of purchase, subject to the following conditions and limitations.

1. Install and operate this Electric Stove in accordance with the installation and operating instructions furnished with the product at all times. Any unauthorized repair, alteration, willful abuse, accident, or misuse of the product shall nullify this warranty.
2. This warranty is non-transferable, and is made to the original owner, provided that the purchase was made through an authorized supplier of the product.
3. The warranty is limited to the repair or replacement of part(s) found to be defective in material or workmanship, provided that such part(s) have been subjected to normal conditions of use and service, after said defect is confirmed by the manufacturer's inspection.
4. The manufacturer may, at its discretion, fully discharge all obligations with respect to this warranty by refunding the wholesale price of the defective part(s).
5. Any installation, labor, construction, transportation, or other related costs/expenses arising from defective part(s), repair, replacement, or otherwise of same, will not be covered by this warranty, nor shall the manufacturer assume responsibility for same.
6. The owner/user assumes all other risks, if any, including the risk of any direct, indirect or consequential loss or damage arising out of the use, or inability to use the product, except as provided by law.
7. All other warranties – expressed or implied –with respect to the product, its components and accessories, or any obligations/liabilities on the part of the manufacturer are hereby expressly excluded.
8. The manufacturer neither assumes, nor authorizes any third party to assume on its behalf, any other liabilities with respect to the sale of the product.
9. The warranties as outlined within this document do not apply to non accessories used in conjunction with the installation of this product.
10. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This warranty is void if:
 - a. The fireplace is subjected to prolonged periods of dampness or condensation.
 - b. Any unauthorized alteration, willful abuse, accident, or misuse of the product.
 - c. You do not have the original receipt of purchase.


IF WARRANTY SERVICE IS NEEDED

Contact the manufacturer by calling customer service department at 1-888-674-7517. Our Consumer Service department is available Monday – Friday 8:30 am – 5:30 pm EST. Make sure you have your warranty, your sales receipt, location of purchase and the model/serial number of your product.

TROUBLESHOOTING GUIDE

PROBLEM	ROOT CAUSE	CORRECTIVE ACTION
No power, switches do not light up.	Power cord was not plugged into the outlet.	Check that the unit is plugged into a standard 120V outlet.
Stove does not turn on manually.	No incoming power from the electrical wall sockets or switches.	Check circuit breakers and move unit to another outlet.
	Improper operation.	Manually press main power button from back of unit.
Flames are not moving.	Defective switch.	Replace power switch.
	Defective flame generator drive motor.	Replace flame generator drive motor.
Flames are not bright.	Spinner detached from the motor.	Remove the back panel and check to see if "spinner" is correctly mounted to the motor.
	Normal operation.	Turn brightness dimmer knob until desired brightness is achieved.
No flame effect and heater is turning on.	Defective Flame Circuit Assembly.	Replace Flame Circuit Assembly.
	Defective Power Circuit Assembly.	Replace Power Circuit Assembly.
Heater is not turning off.	Defective Thermostat.	Replace Thermostat.
	Improper operation.	Manually press main power button on back of unit.
Heater is not turning on.	Defective switch.	Replace heater switch.
	Defective heater blower motor.	Replace heater/blower assembly.
Not producing enough heat.	Power strip/surge protector / extension cord being used.	Plug unit directly into the wall.
	Location of unit.	Make sure unit is located on an interior wall.
Unit blows cool or cold air.	Defective heater blower motor.	Replace heater/blower assembly.
Noise with heater on.	Dirty heater blower motor.	Clean heater blower motor.
	Defective heater blower motor.	Replace heater/blower assembly.
Noise with flames on and heater off.	Defective flame generator drive motor.	Replace flame generator drive motor.
	Dented back panel.	Refer to TSI customer service.
Power cord gets warm.	Warped spinner shaft.	Refer to TSI customer service.
	Normal operation.	Check your heater cord and plug connections. Faulty wall outlet connections or loose plugs can cause the outlet or plug to overheat. Be sure the plug fits tight in the outlet. Heaters draw more current than small appliances, so overheating of the outlet may occur even if it has not occurred with the use of other appliances. During use check frequently to determine if your plug outlet or faceplate is HOT! If so, discontinue use of the heater and have a qualified electrician check and/or replace the faulty outlet(s).
Is it safe to place unit on carpet?	Product Inquiry.	It is safe to place unit on carpet, but make sure any flammable items are at least 3 feet away from front and sides of the unit.
How many square feet will my unit warm up?	Product Inquiry.	Provides supplemental heat up to 1000 square feet.
Heater doesn't work, but Power and Heater switches are in the "ON" position and thermostat is set on the highest level.	The thermal protector has tripped.	Turn all switches to the "OFF" position and unplug the unit from the wall outlet for 5 minutes. After 5 minutes, plug the unit back into wall outlet and operate as normal.

EXPLODED VIEW

PART	DESCRIPTION	Part Number	
1	Power Switch	P06-S	
2	Thermostat	P03-S	
3	Thermostat knob	P05-S	
4	Heater Switch	P06-S	
5	Dimmer Knob	P04-S	
6	Dimmer Switch	P07-S	
7	Feet (Left/Right)	SF-S344-01(DFI-7095-01) SF-S344-02(DFI-7095-02) SF-S344-03(DFI-7095-03) SF-S344-05(DFI-7095-05) SF-S344-D989(DFI-7095-D989)	
8	Logset	Y19-S272-LOG	
9	Heater/Blower Assembly	Y16-S181-P01	
10	Flame Generator Drive Motor	P10-Q-S	
11	Door Handle	Y24-S344-DH	

CARE AND MAINTENANCE

- Clean the trim using a soft cloth, slightly dampened with citrus oil based product and buff with a clean soft cloth.
- DO NOT use brass polish or household cleaners as these products will damage the metal trim. Citrus oil based products can be obtained at supermarkets or hardware stores.
- WARNING: Electrical outlet wiring must comply with local building codes and other applicable regulations to reduce the risk of fire, electrical shock and injury to persons.
- WARNING: Disconnect power before attempting any maintenance or cleaning to reduce the risk of fire, electrical shock or personal injury.