temp-tations by Tara

TEMP-TATIONS 2.3-QT SEASONAL ENAMEL ON STEEL TEA KETTLE

BEFORE FIRST USE

- Remove any packaging, stickers, or labels.
- Wash in warm, soapy water with mild dishwashing soap. Rinse and dry.
- Fill with clean water, bring to a boil, and discard this water. Kettle is ready to use!

PRODUCT INFORMATION/ FEATURES

- Compatible for use on all stovetops, including induction.
- Enamel on steel construction.
- Whistles when boiling.
- 2.3 quart capacity.

USE

- DO NOT overfill the kettle. Overfilling the kettle can cause boiling water to be forced out of the spout, resulting in SEVERE INJURIES AND BURNS. The water level should always be below the spout on the inside of the kettle.
- NEVER heat an empty kettle. Heating an empty kettle dry may result in damage to the kettle or cooktop.
- DO NOT allow the kettle to boil dry. Boiling the kettle dry may result in damage to the kettle or cooktop. If the kettle has been allowed to boil dry, turn off the heat and allow the kettle to completely cool before attempting to remove from the cooktop.
- ALWAYS use a burner on the back row of the stove to keep it out of the reach of small children.
- ALWAYS ensure the lid is firmly in place on the kettle.
- ALWAYS match the kettle base size to the burner size it is to be used on. Gas flames must always be confined to the base area and not extend up around the side walls of the kettle.

- DO NOT leave a heating kettle unattended and do not rely on the whistle to remind you about an unattended kettle. The whistle is for convenience. It is not a safety device.
- Kettle handle and whistle may get hot. ALWAYS WEAR OVEN MITTS WHEN HANDLING KETTLE OR FLIPPING THE WHISTLE LEVER OPEN to prevent possible burn injury.
- After removing the kettle from the heat source, wait 10 seconds before opening the whistle lever. This step ensures that any rapid boiling has stopped.
- ALWAYS POINT THE SPOUT AWAY FROM YOU WHEN BOILING WATER OR OPENING THE SPOUT.
- Steam escaping from the lid or spout can burn you. DO NOT open the lid until water has cooled, or wear an oven mitt to protect your hand.
- NEVER tip kettle upside down when pouring.
- Allow kettle to cool completely before refilling. NEVER refill a hot kettle with cold water.
- Avoid knocking or banging your kettle on hard surfaces, as this can damage the enamel coating.

CARE

- Hand wash in warm, soapy water. Dry thoroughly.
- Over time, limescale deposits may build up on the interior of the kettle when used in areas where hard water is present. This is normal but may affect the time is takes for water to boil. To protect against the build-up of limescale, we recommend to always empty the kettle after each use.
- When needed, we recommend either using
  a) a gentle kettle descaler or b) a water and white vinegar solution.
  - To descale with a kettle descaler, follow the manufacturers instructions.
  - To descale with a water and white vinegar solution, simply pour 2 cups of water and $^1/_4$ cup of distilled white vinegar into your kettle. Bring the solution to a boil and turn off the heat. Let it sit for 20 minutes, then pour out the solution. Wash in warm, soapy water.

Something wrong? Don't worry!
Contact us first and give us a chance to make it right!

If you are missing parts, received a damaged product, or need assistance with "how to use", we are here to help! Call us at 866.757.2333 or email us at customercare@henninglee.com. M-F (9am – 5pm CT)

Henning Lee, LLC, Minneapolis, MN 55419 • Customercare@henninglee.com • (866) 757.233 Made in China