

BEFORE YOU BEGIN

Tempaper is recommended for smooth surfaces that are in good condition and have been primed and painted with a satin or semi-gloss finish. Clean surface by wiping with a damp cloth or wet rag, making sure surface is fully dried before application. For an easier install, remove switch plates and outlet covers prior to installation making sure to turn off electricity at source prior to removal.

If applying to a surface that has been painted with a zero VOC paint, wiping surface with a 1:1 Isopropyl alcohol and water solution prior to application may help with adhesion.

SURFACES NOT RECOMMENDED

- Matte, flat, and low sheen paints
- Textured surfaces
- Exterior surfaces

TOOLS

- Craft knife
- Cutting surface
- Level
- Pencil
- Ruler or straight edge
- Step stool
- Squeegee
- Tape measure

Satisfaction Guaranteed - Limited Warranty

This product is warranted to perform when applied to a properly prepared surface in accordance with the label directions.

This warranty excludes labor or the cost of labor for the application of any product and excludes any incidental or consequential damages.

APPLICATION

1. Measure the height and width of your surface, this will determine how many panels you will need.
2. Pre-cut your first panel to the height of your surface adding 2-3 inches of excess material at the bottom.
3. Be sure to align pattern with each consecutive panel prior to cutting, numbering the back of each panel as you work.
4. Using a level, mark a vertical guide down the length of surface.
5. Peel back 3-4 ft. of the backing.
6. Begin at the top edge aligning paper with your vertical guide to ensure a straight application.
7. Use a squeegee to smooth paper to surface working from the center out. Tempaper can be repositioned as needed to ensure pattern alignment and to eliminate bubbling.
8. Continue in 3-4 foot increments peeling and smoothing until you reach the bottom edge of your surface.
9. Repeat steps 5-8 until the surface has been fully covered.
10. Trim where needed with a craft knife to complete your application.

For directions on working from the roll, please visit tempaper.com/learn

REMOVAL

Starting with any corner, firmly peel up or down slowly parallel to the surface.

Tempaper has been tested on and successfully removed from various surface types and conditions. LolliProps Inc. may not be held responsible for damaged surfaces or for difficulty of removal.

FOR DETAILED HOW-TO VIDEOS, PLEASE VISIT [TEMPAPER.COM/LEARN](https://tempaper.com/learn)