



FoodSaver®

THE #1 VACUUM SEALING SYSTEM



FM2800 series shown

User Manual

for FM2800 series appliances

www.foodsaver.com 1-877-777-8042



Accessories maximize the versatility of your FoodSaver® appliance!

A full range of FoodSaver® Vacuum Sealing Accessories let you keep almost all foods fresh longer in the freezer, refrigerator and pantry. In addition to foods like meat and cheese that you vacuum package with FoodSaver® Bags and Rolls, our Containers and Canisters allow you to vacuum package leftovers, deli meats and cheeses, dry goods, snacks, cookies and crushable items so they'll stay crisp and full of flavor for weeks. Want to save tonight's delicious stew for second servings? Simply vacuum package in a FoodSaver® Container and refrigerate. And our Quick Marinator can help you to marinate meat in minutes, not hours.

Go to www.foodsaver.com to purchase rolls, bags and accessories.

FoodSaver® Bags and Rolls

FoodSaver® Bags and Rolls provide exceptional freshness protection for food. Special channels enable the efficient removal of air. The multi-ply construction provides an especially effective barrier to oxygen and moisture. They are proven to help prevent freezer burn. FoodSaver® Bags and Rolls can be used in the freezer or refrigerator and can be used to reheat foods in the microwave or by simmering on the stove top.

FoodSaver® Bags (Pint, Quart and Gallon sizes) are ready made, so they're convenient and easy to use. FoodSaver® Rolls (8 in. x 20 ft. and 11 in. x 16 ft.) are versatile and allow you to make custom lengths to fit every vacuum packaging need.



FoodSaver® Zipper Bag Adapter



The specially designed FoodSaver® Zipper Bag Adapter is for use with FoodSaver®, FoodSaver® GameSaver® and Seal-a-Meal® heat seal vacuum appliances. The Adapter fits onto the end of the accessory hose to enable evacuation through the valve of FoodSaver® Vacuum Zipper Bags. *Works with all models (excludes 4800 series, FM2100 and FM2000).

NEW FoodSaver® Handheld Sealer



The FoodSaver® Handheld Sealer is designed to work with FoodSaver® vacuum zipper bags, containers, canisters, and ALL other FoodSaver® accessories including wine stoppers, jar sealers and the Quick Marinator,

without requiring additional adapters, or parts. * Works with FM2000 and FM21000 Series only.



FoodSaver® FreshSaver® Zipper Bags

FoodSaver® FreshSaver® Zipper Bags are for use with FoodSaver® FreshSaver® handheld vacuum sealers. FoodSaver® FreshSaver® Zipper Bags also work with standard FoodSaver® Heat Seal Appliances by using the Zipper Bag Adapter and Handheld Sealer (sold separately). The extra strong double track zipper and multi-ply material locks air out and freshness in. Zipper Bags keep fresh foods and snacks fresh longer and are great for everyday use.



Left: Quart Zipper Bag, (available in 18 ct)
Right: Gallon Zipper Bag (available in 12 ct)

FoodSaver® Freeze 'n Steam™ Microwave Cooking Bags

The FoodSaver® Freeze 'n Steam™ Bags stand up for easy filling. Once vacuum sealed, you can freeze your vegetables and meats until you are ready to cook them. Freeze 'n Steam™ Bags go right from the freezer to the microwave-special vents in the bag allow for perfect steaming!

Quart Freeze 'n Steam™ Bags available in 16 ct



FoodSaver® Liquid Block Bags



The FoodSaver® Liquid Block bags are ideal for vacuum sealing juicy and moist foods. The liquid blocking strip prevents moisture from escaping the bag, creating a strong, clean seal. Liquid Block bags come in a convenient quart size that makes them perfect for sealing marinated foods, raw meats, and juicy leftovers with no mess and no leak!

FoodSaver® 11" Portion Pouch™ Rolls

The FoodSaver® 11" Portion Pouch™ Rolls seal in freshness and preserve food flavors. The roll is perforated in the middle to allow for sealing two things at once! Perfect for storing leftovers and individual size portions, or bulk seal your food twice as fast.



NEW FoodSaver® Expandable Rolls

The FoodSaver® Expandable Rolls are the ultimate solution to storing extra large foods without cutting them up first. The Expandable Roll accommodates large roasts, whole turkeys, even casserole dishes with no mess and no fuss. Prepare meals ahead of time and transport them right in the pan without sacrificing freshness.



FoodSaver® Deli Containers

FoodSaver® Deli Containers are a convenient way to store your leftovers, make-ahead lunches, deli meats, cheeses, and snacks. They are stackable, dishwasher safe, and a perfect storage option for the refrigerator or pantry.



Left: Container 2 Piece Set (1/2 qt.)
*Includes container adapter

FoodSaver® Sandwich & Snack Containers

The FoodSaver® Sandwich & Snack Containers keeps foods fresh longer compared to unwrapped foods. The containers can be used in the refrigerator or pantry. Microwave-safe material makes reheating fast and convenient.



Above: Container 2 pack Set (25oz ea.)
*Includes container adapter



Above: 2 Quart Vacuum Packaging Canister with Cheese Grater

FoodSaver® Rectangular Canister

Save space in the fridge with this low-profile rectangular shape. Our design with latches ensures that lids are secured tightly, whether the canister is vacuumed or not. Rectangular Canisters are perfect for storing leftovers such as casseroles, lasagna, cooked vegetables and cheese.

FoodSaver® Round Canisters

These multi-purpose canisters are ideal for storing crushable items and liquids, as well as dry goods and cooking staples. The canisters come in a variety of shapes and sizes and all look great on your kitchen counter or in the pantry.

- Accessory Hose is sold separately for Canisters.



Left: 3-Piece Vacuum Packaging Canister Set

- 3/4 quart
- 1 1/2 quart
- 2 1/2 quart

Please note: Vacuum packaging is not a substitute for canning, refrigeration or freezing.

FoodSaver® Quick Marinating Canister

Marinate in minutes instead of hours. During the vacuum process, the pores of meat, fish, poultry and other foods are opened up, allowing marinades to penetrate deeper and more quickly, so your favorite recipes can get started in no time. Perfect for the home chef, the 2 1/4 quart square canister can also be used for convenient vacuum storage. Check out www.foodsaver.com for great marinating recipes and other tips.



FoodSaver® Jar Sealers

With FoodSaver® Jar Sealers, you can use your own Ball®, Kerr, and Mason jars to vacuum seal liquids, fragile foods and dry goods like brown sugar, spices, dried fruit and coconut – or your own homemade gifts.



The handy, reusable sealers come in two sizes:

- Wide-Mouth and Regular

FoodSaver® Bottle Stoppers

FoodSaver® Bottle Stoppers will help you vacuum package bottles to protect the taste and extend the life of liquids such as wine and cooking oils.

Sold in sets of 3



Tips For Using FoodSaver® Accessories

You can access information and tips about FoodSaver® accessories on our website www.foodsaver.com. Plus, go online and sign up to get our FoodSaver® products email updates so you'll be the first to know about new products, usage tips and more!

Here's a sampling of the great accessory ideas FoodSaver® brand customers have sent us:

"I read in a 'helpful hints' book that silver jewelry tarnishes faster when exposed to air, so I bought a set of FoodSaver® Containers to use especially for my silver jewelry. This has really cut down on the time I spend polishing my jewelry – it works for cutlery, too!" – *Laura E.*

"We use large FoodSaver® Containers or large Mason jars and cut up all our lettuce and dry vegetables (peppers, onions, etc.) once a week following a trip to the produce market. Salads are only a moment away for lunch or dinner by adding the wet veggies (tomatoes, cucumbers, etc.)." – *Denise G.*

"I save a lot of money when I buy the big cans of dog food for my toy poodle, but he can't eat all of it in one sitting, so I vacuum package the rest in a FoodSaver® Container to use day by day." – *Patsy B.*

"I always juice my own vegetables for fresh juice. I used to juice and clean up the mess every day. Now, with my FoodSaver® Containers, I can juice 4-5 days worth of juice, seal it in a container, and put it in the fridge. Each day I can pour myself a glass of fresh juice, reseal the container and replace it in the refrigerator." – *Arthur T.*

Accessory Hose is included in all FoodSaver® vacuum sealing appliances.



Accessory hose is not included with purchase of Zipper Bag Adapter, Canisters, Containers, Marinator, Jar Sealers, and BottleStoppers. * Sold separately at Foodsaver.com.

For more tips and information, visit www.foodsaver.com or call 1-877-777-8042

All items subject to availability. Prices subject to change.
©2016 Sunbeam Products, Inc. doing business as Jarden Consumer Solutions. All rights reserved.
PN: 179266 CSDT052516 FSV46244



Get the most from your FoodSaver® system with these versatile accessories

How to Vacuum Package with FoodSaver® Accessories

1. Prepare container according to *FoodSaver® Accessory Instruction Manuals*.
 2. Insert one end of Accessory Hose into Accessory Port on appliance. Insert other end into port on accessory. Twist tab on Accessory Hose while inserting to ensure a tight fit.
 3. Close lid, rotate Latch, press Vacuum & Seal Button.
 4. When motor and Indicator Light turn off, vacuum process is complete. Note that the appliance will still go through sealing cycle even when vacuuming an accessory. You will hear Motor shut off and then the sealing cycle will begin.
 5. Gently twist and remove Accessory Hose from accessory and appliance.
 6. To test vacuum, simply tug on using accessory lid. It should not move.
- Note:** For important tips on using accessories with different foods, please refer to the *FoodSaver® Guidelines for Vacuum Packaging*.

How to Open FoodSaver® Accessories after Vacuum Packaging

FoodSaver® Vacuum Packaging Canisters (without large knob on lid)

To release vacuum and open, push gray rubber button on lid.

FoodSaver® Bulk Canisters and Quick Marinators (with large knob on lid) and Universal Lids

To release vacuum and open, turn knob on lid to Open.

FoodSaver® Jar Sealer with Mason Jars

For use with Ball® and Kerr® brand Mason jars.

Important: Do NOT use screw bands when vacuum packaging jars. To open, wedge spoon between Mason jar lid and highest part of threaded rim. Twist spoon gently to release vacuum.

FoodSaver® Bottle Stoppers

To release vacuum and open, twist and pull up on Bottle Stopper.