



### Features

**Smart Identification:** Built-in identification chip for power input & output through a single USB port.

**Smart Control:** Control the charging current automatically and fully charge the device efficiently.

**Sleep Mode:** Automatic Sleep Mode saves battery when not in use.

**Speedy Charging:** 2 Amp high current can speed up charging time.

**Ultra Slim Design:** 1/4" thick for easy portability. Fits neatly into jacket pocket or hand bag

**Light Weight:** Weighs less than 5 ounces making it lighter weight than an iPhone 4S.

**Battery Efficiency:** Intelligent voltage reducing technology increases the battery efficiency to 85%.

**Quick charging, high working efficiency.**

**Overcharging and overdischarging protection.**

**Short circuit protection.**

**!** Read all safety information, warnings and operating instructions before using your XL 4200 to avoid personal injury and damage to your device(s). We assume no responsibility for damage due to improper operations of this power charger.

### Battery Life Extension

IPHONE 3	≤250%
IPHONE 4/4(S)	≤220%
IPHONE 5	≤220%
IPOD TOUCH	≤310%
IPAD MINI	≤50%
IPAD 2	≤40%
IPAD 3	≤40%
SAMSUNG GALAXY S	≤200%
SAMSUNG GALAXY S III	≤130%
SAMSUNG GALAXY NOTE II	≤80%
BLACKBERRY BOLD	≤250%

### Compatible with

### Components of XDREAM XL

### Accessories

USB to USB/DC output cable x 1

30 PIN x 1

iPhone 3  
iPhone 4/4s  
iPad Gen.1  
iPad Gen.2  
iPad Gen.3  
iPod  
iPod nano  
iPod Touch  
iPod Shuffle

Micro USB x 1

HTC HD7  
HTC One X  
LG Optimus  
Nokia Lumia 920  
Blackberry Bold  
Blackberry Curve  
Blackberry Storm  
Motorola Droid  
Google Nexus 4/7  
Samsung Galaxy S3  
Samsung Galaxy Note  
Sony Xperia S LT26i  
Sony Ericsson Xperia X10

Mini USB x 1

Canon 450D  
HTC Droid Eris CDMA  
Motorola Sidekick  
Motorola Q  
Motorola Sliver  
Motorola RAZR V3  
Blackberry 62xx  
Blackberry 7100  
Blackberry 8100  
Blackberry 8320  
Blackberry 8800

### Demonstration

Step 1

Step 2

Pouch x 1

### Getting Started

First charge your XL 4200 to its full capacity. This may take up to 6 hrs. Failure to fully charge your XL4200 before first use may reduce battery efficiency.

### To Charge XL 4200

You may charge your XL4200 through the USB port of your computer or through an AC adapter with built-in USB interface. Please note that your XL 4200 does not come with a dedicated AC adapter. You may use any 5V USB interface adapter such as adapters of iPhone, iPod, iPad, Nokia, etc.

To charge XL 4200, insert either USB end of supplied cable into port of XL 4200. Plug the other USB end of supplied cable into 5V wall adapter USB port or into USB port of your computer.

The battery indicator lights of XL 4200 will flicker one by one in direction of the arrow, indicating charging is taking place. When all indicator lights are fully lit, charging is complete.

- The maximum input voltage of XL 4200 is 5V. Please read specification of any AC adapter used to insure compatibility.

### To Charge Personal Electronic Devices

Plug either USB end of supplied cable into USB port of XL 4200. Insert

appropriate supplied tip for your device into tip port of supplied cable.

XL 4200 will automatically recognize your device and begin charging. The LED indicator lights will flicker one by one in the direction of the arrow. When your device is fully charged all indicator lights will be lit. Please note

that once your device is fully charged, the XL 4200 will automatically enter Sleep Mode to conserve battery power. However, indicator lights will remain lit.

Please note your XL 4200 has built-in protection that will automatically shut down when battery capacity drops below necessary current and voltage to charge connected device. In the case of tablets and other high current/voltage devices, this may happen when XL4200 drops to 30% capacity or less.

You may also use the dedicated USB cable provided with your device instead of supplied XL 4200 cable. In the case of iPhone 5, it will be necessary to use the cable supplied with your phone.

You may simultaneously charge your device and the XL 4200, by first plugging the other USB end into power source before connecting your

device. In this case the LED lights will flicker in the direction indicating charging of XL 4200. However, your device's indicator will be on.

### Power & Capacity Indicator

To check battery capacity at any time, simply push and release battery status button. Indicator lights will come on. If no indicator lights are lit, the XL 4200 is completely out of power.

0%~25% capacity    25%~50% capacity  
50%~75% capacity    75%~100% capacity

- Running down of battery [All LED lights off]
- Charging complete [All LED lights on]

Please note your XL 4200 has intelligent software built-in. There is no ON/OFF switch. It will automatically recognize your device

and begin charging. Once device is unplugged, XL 4200 will automatically power down. Your XL 4200 will hold its charge for 3 months when not in use. It is recommended that you charge the XL 4200 every 2 months, if not in use, for optimum performance. Important: When using XL 4200 after extended period of non-use(6-8wks), be sure to fully use remaining battery capacity and then recharge to full capacity.

### Technical Data

Product Dimensions: 5.3 x 2.6 x 0.35 inches  
Product Weight: 0.295 lbs

Battery Capacity:	4200mAh
Battery Voltage:	3.7V
USB Input Voltage:	5V
USB Input Current:	700mA
USB Output Voltage:	5V
USB Output Current:	2000mA

### Trouble Shooting

**Can't Charge XDREAM XL through an Adapter**  
Make sure the USB cable connection is properly connected. Confirm that the adaptor's output voltage and current must comply with XL's charging requirements. Please refer to the instruction manual of the adaptor you use for its output voltage and current.

**Can't Charge Other Devices**  
XDREAM XL is out of battery. Recharge XL to full before use. USB needs to be reseated. Reseat the USB cable and wait for a few seconds. Check the source device's input requirements. If the device's input requirements for voltage and current are higher than XL's, then XL cannot charge the device. Please refer to the instruction manual of your device.

**No Indicator Lights Are Lit When Battery Status Button Is Pressed**  
XDREAM XL is out of battery. Please re-charge XL to full before use.

**Battery Efficiency Reduced**

When out of service for a long period, it is recommended to retain 30% of power and charge the XL 4200 every 2 months.

### Warnings

Failure to follow these safety instructions could result in fire, electric shock, personal injury or other damage.

- Do not place XDREAM XL in high-temperature environments, including strong sunlight and fire.
- Do not drop, disassemble, puncture, open shred, incinerate, paint or subject to a heavy blow. In the event that XDream XL is damaged in any way, do not use.
- Do not insert foreign objects into XDream XL.
- Do not store XDREAM XL in a damp area. Do not expose XDream XL to rain, snow, moisture, water or spray. Take care to not spill food or liquids on XDream XL. In the event that this device gets wet, unplug all cables and allow to thoroughly dry

before attempting to use. Do not attempt to dry XDream XL by any external source such as blow dryer or microwave. If XDream XL has been submerged in water or liquid, do not use. A power charger that has been damaged by exposure to liquids is not serviceable.

- Use only the included USB charger cable to charge your XDREAM XL. Using other USB charger cables may cause irreparable damage to your XDream XL.
- Never force a connector into a port. If the connector and port do not join with reasonable ease, they probably do not match. Make sure that the connector matches the port and that you have positioned it correctly in relationship to the port.
- Your XDream XL will experience a rise in temperature while in use. Please make sure it is exposed to air while in use. Do not cover the XDream XL with any other item

while in use. If the XDream XL is overheating, swelling, moisturizing, or there are any abnormal conditions, please discontinue use immediately.

- Never attempt to repair or modify this power charger by yourself. Disassembling this power charger, including the removal of external screws, may cause damage that is not covered under the warranty. Incorrect reassembly may result in shock or fire hazard. If this power charger has been submerged in water, punctured, or subjected to a severe fall, do not use it.
- Children or the elderly should use the product under supervision.

### FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) this device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.

15.21  
You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105(b)  
This equipment has been tested and found to comply with the limits for Class B digital devices, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not

installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

DO NOT dispose of unit with general waste. Contains lithium polymer battery. Please return it to battery recycling collection center. For recycling center near you, call 1-877-2-RECYCLE.

FC CE RoHS

### LIMITED MANUFACTURER'S WARRANTY

X-Dream warrants its products to be free from defects in material and workmanship under normal use and conditions, as follows:

- During the first ninety (90) days from date of purchase, X-Dream will repair or replace the defective product.
- X-Dream will, subject to inspection, repair the defective product or replace it with a new or reconditioned unit at its sole discretion.
- Warranty returns must be shipped prepaid. A shipping rebate will be extended to the customer only in the event that a defect in material or workmanship is confirmed.
- Warranty is void if the product has been improperly handled or misused in any way, or if the label and/or bar coded warranty label has been removed or tampered with.
- Warranty returns require a check for \$16.95 for processing and

handling made payable to DBOD Marketing, LLC.

- Where applicable, all requests for warranty returns must be accompanied by a proof of purchase and be made to DBOD Marketing, LLC
- This warranty does not extend to the electronic equipment that is used or which incorporates with any of our products and accessories. X-Dream/DBOD
- Marketing, LLC shall not be held responsible for the improper use of its products.
- Warranty returns should be addressed to:  
X-Dream c/o DBOD Marketing/ LLC  
125 St Andrews  
Smithfield, VA 23430  
To contact us (888) 864-5553

Made in China  
Distributed by DBOD Marketing, LLC  
authorized distributor of XDREAM™

