

Model No. 4045

Aqualite

**WATERPROOF 10-Watt
CREE LED SPOTLIGHT**

Instruction Manual



**MOBILE
POWER**

MobilePower, LLC • Bluffton, SC 29910

www.Mobilpower-us.com

Office: (800) 708-8550


customerservice@mobilepower-us.com



AQUALIGHT ITEM #4045
WATERPROOF 10-Watt
CREE LED SPOTLIGHT

WELCOME

This product has been carefully engineered and manufactured to give you dependable operation. Please read this manual thoroughly before operating your new product as it contains the information you need to become familiar with its features and obtain the performance that will bring you continued enjoyment for many years. Please keep this manual on file for future reference.



FEATURES:

- 10 Watt LED Bulb
- High/Low/Strobe Beam Control
- Charge Status LED Indicator
- Trigger Switch
- Rubber Bezel
- Waterproof End Cap
- Charge Status LED Indicator
- Charging Port
- 110 Volt AC Charger
- 12 Volt DC Charger

READ ALL INSTRUCTIONS

WARNING: Read all instructions before operating spotlight. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: This product or its power cord contains lead, a chemical known to the State of California to cause cancer and birth defect or other reproductive harm. Wash hands after handling.

INSTRUCTIONS PERTAINING TO RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

WARNING: WHEN USING ELECTRICAL APPLIANCES, BASIC PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

To reduce the risk of injury, close supervision is necessary when the spotlight is used near children.

Use only attachments recommended or sold by the manufacturer.

WARNING: TO REDUCE THE RISK OF ELECTRIC SHOCK:

- Charge indoors only. Do not expose chargers to water or any other liquid.
- Use only the charger supplied by the manufacturer to recharge.
- When an extension cord is used:
 - The marked rating of the detachable power supply cord or extension cord should be at least as great as the electrical rating of this appliance.
 - The cord should be arranged so that it will not drape over the countertop or tabletop where it can be tripped over, snagged, or pulled on unintentionally (especially by children).
 - The extension cord should be kept dry and off the ground.

WARNING: FIRE HAZARD: Keep spotlight lamp away from materials that may burn.

CAUTION: TO REDUCE THE RISK OF INJURY OR PROPERTY DAMAGE:

- 10W LED gets hot quickly. Do not touch hot lens, guard or enclosure. Never look directly into the light or shine the light into another person's eyes.
- Keep sharp objects away from lens it can crack or break.
- Do not expose this unit to extremely high temperatures.

- Do not expose this unit to extremely high temperatures.
- Do not drop or throw spotlight. It contains a nickel metal hydride rechargeable battery pack.
- Use only with AC or DC charging adapters that are provided with unit. Plug in the charging adapter at the spotlight first, then plug into the charging source.
- Do not overcharge: Recharge up to 18 hours maximum.
- Do not crush, cut, pull or expose charging adapter cords to extreme heat.
- Position charging adapter cords so they do not become entangled or become a safety hazard. Keep charging adapter cords away from sharp edges.
- Do not open body casing. There are no user-serviceable parts inside.
- Do not operate the spotlight without the lens in place.
- To reduce risk of damage to electric plug and cord, pull by plug rather than cord when disconnecting.
- Do not attempt to charge the unit if the charger is damaged.

CHARGING/RECHARGING THE SPOTLIGHT

This unit is shipped in a partially charged state. Charge unit BEFORE first use using the provided charger for approximately 12-14 hours. or until the Charge Status LED Indicator on the spotlight is OFF.

Charge after each use until the Charge Status LED Indicator is OFF.

Battery will hold its charge for a period of time. However, we recommend recharging your spotlight every 3 months if not in use.

CAUTION: TO REDUCE THE RISK OF PROPERTY DAMAGE:

Make sure the unit is thoroughly dry before charging or recharging. If the unit has been submerged, wipe it dry with a soft cloth before opening the end cap. If water leaks into the charging port, the unit can sustain permanent damage.

CHARGING/RECHARGING USING THE 120 VOLT AC CHARGER

- Make sure the spotlight is turned off.
- Unscrew (counterclockwise) the waterproof end cap on the back of the unit and remove it.
- Insert the barrel connector of the AC charger into the charging port on the back of the unit. Insert the plug end into a standard North American 110 volt 60Hz outlet.
- The Charge Status LED Indicator lights RED during charging process.
- Charge until the Charge Status LED Indicator is OFF (approximately 12-14 hrs).
- Disconnect the charger from the spotlight.
- Replace the end cap on the unit, screwing clockwise until it fits securely.
- Unplug charger after the spotlight is fully charged. Wait 5 Minutes before using.

CHARGING/RECHARGING USING THE 12 VOLT DC CHARGER

- Make sure the spotlight is turned off.
- Unscrew (counterclockwise) the waterproof end cap on the back of the unit and remove it.
- Plug the barrel tip of the supplied 12 volt DC charger into the charging port on the back of the unit..
- Insert the 12 volt DC plug end into the accessory outlet of your vehicle or other 12 volt DC power source.
- The Charge Status LED Indicator lights RED during charging process.
- Charge until the Charge Status LED Indicator is OFF (approximately 12-14 hours).
- Disconnect the charger from the spotlight.
- Replace the end cap on the unit, screwing clockwise until it fits securely.

Note: When using a vehicle's 12 volt DC accessory outlet as a charging source, be aware that some vehicles require you to turn on the ignition to power the accessory outlet.

Unplug charger after the spotlight is fully charged. Wait 5 Minutes before using.

OPERATION INSTRUCTIONS:

Operating the spotlight

Important note: When either charger is plugged into the 12 volt DC port, the unit is in charging mode. The spotlight will not run with either of the chargers plugged in.

- 1.** Disconnect from charger.
- 2.** The trigger switch is located in the front of the handle of the spotlight.
- 3.** Press 1st time = High beam (Full charge will provide around 4hrs running time)
- 4.** Press 2nd time = Low beam (Full charge will provide around 8hrs running time)
- 5.** Press 3rd time = Strobe Flashing (For emergency purpose)
- 6.** Press 4th time = Spotlight will be in OFF position

The Spotlight will be automatically turned ON when it drops into the water.

The Spotlight will be automatically turned OFF when the battery is out of power.

SPECIFICATIONS

Bulb:	10 watt CREE LED bulb
Battery:	2 x Maintenance-free, Lithium, 3.7 volt, 2200 mAh
AC charger:	110 volt AC 6 Volt DC 300mA
DC charger:	12 volt DC (2A fused)



MobilePower, LLC. warrants to the original purchaser that this portable lighting unit shall be free from defects in material and workmanship for a period of one year from the original date of purchase. If the product is determined by MobilePower, LLC to be defective in material and workmanship during the warranty period MobilePower, LLC will repair or replace the defective product or defective accessories/components with factory original specification product at its option. The original purchaser is authorized to obtain this warranty with the proof of purchase within the warranty period. To obtain shipping instructions related to the warranty services in North America visit us at

www.mobilepower-us.com, call 800-708-8550 Customer Support or contact us at customerservice@mobilepower-us.com.

You may ship the defective product with freight prepaid to MobilePower, LLC. Your replacement will be shipped back to you at no additional charge.

Great care must be taken when packing the product and all associated accessories into a suitable packing box along with the original dated purchase receipt or invoice. The package must include a letter stating the defect details, contact information including physical address. Any address with a PO Box will not be processed and will be held until further notification from the consumer.

Make certain that your package can be tracked when you are shipping the defective products to us.

MobilePower, LLC will not be responsible for lost packages sent by consumers. MobilePower, LLC. Will not be responsible for damages incurred during shipment to our facilities. Failure to provide the original purchase receipt or proof of purchase will render this warranty invalid.

THIS WARRANTY SHALL NOT APPLY IF THIS PRODUCT IS:

(A) DAMAGED RESULTING FROM ABUSE, MISUSE, NEGLIGENCE, ACCIDENT, LACK OF MAINTENANCE, ABNORMAL WEAR AND TEAR, UNREASONABLE USE OR BY OTHER CAUSES UNRELATED TO DEFECTIVE MATERIAL OR WORKMANSHIP (B) IS USED FOR COMMERCIAL PURPOSES; (D) IF THE PRODUCT HAS BEEN SUBJECTED TO WATER OR FIRE.

This warranty provides you with specific legal rights, & you may also have other rights which vary from state to state. This warranty is valid only in North America.

MobilePower, LLC. Bluffton, SC 29910

www.mobilepower-us.com

Customer Support: (800) 708-8550

Customerservice@mobilepower-us.com