

DESIGNED TO BLEND. EQUIPPED TO STAND OUT. UNLIMITED CULINARY POSSIBILITIES



INCLUDED ACCESSORIES & ATTACHMENTS



MULTI-PURPOSE BLADE

Liquefy fruits and vegetables, mince meat.



S-BLADE BLADE
Blend, crush, puree — soups, smoothies, and sauces.



FROTHER BEATER BLADE
Mix, beat, froth — cappuccinos, cake batter, and more.



CHROME WHISK ATTACHMENT
Whip egg whites and cream.



2.5 CUP FOOD CHOPPER
Chop hard cheeses, fruits, and vegetables.



4 CUP BLENDING JAR WITH LID



STORAGE CASE
For hand blender attachments. (Pitcher & Chopper not designed to fit in case.)



BELL BLADE COVER
Protects interchangeable blades when not in use.



PAN GUARD
Helps protect against scratching metal and protects plastic cookware.