

1. GETTING STARTED



INSERT



PLUG IN

2. LIGHT INDICATOR EVOLUTION

1. PREHEATING



PREHEATING

READY TO COOK

2. COOKING STARTS



3. COOKING



RARE

MEDIUM

WELL-DONE

KEEP WARM



MANUAL
FUNCTION



FIXED



IF
FLASHING

CALL
CONSUMER
SERVICE

3. SELECT COOKING PROGRAM



SELECT

OPTIONS



Frozen Food
+ program



Manual mode:
fixed temperature

4. PREHEATING



WAIT

Wait approx 5 min



BEEP = READY

5. COOKING



OPEN




PLACE FOOD



CLOSE
THICKNESS
MEASUREMENT



COOKING STARTS



RARE



MEDIUM



WELL-DONE

REMOVE FOOD AT THE REQUIRED LEVEL



READY TO EAT



CLOSE

6. CLEANING AND MAINTENANCE



OFF



UNPLUG



WAIT



REMOVE



WASH