

KitchenAid®

DESIGNED TO BLEND. EQUIPPED TO STAND OUT. UNLIMITED CULINARY POSSIBILITIES



INCLUDED ACCESSORIES & ATTACHMENTS



MULTI-PURPOSE BLADE

Liquefy fruits and vegetables, mince meat.



S-BLADE BLADE

Blend, crush, puree — soups, smoothies, and sauces.



FROTHER BEATER BLADE

Mix, beat, froth — cappuccinos, cake batter, and more.



CHROME WHISK ATTACHMENT

Whip egg whites and cream.



2.5 CUP FOOD CHOPPER

Chop hard cheeses, fruits, and vegetables.



4 CUP BLENDING JAR WITH LID



STORAGE CASE

For hand blender attachments. (Pitcher & Chopper not designed to fit in case.)



BELL BLADE COVER

Protects interchangeable blades when not in use.



PAN GUARD

Helps protect against scratching metal and protects plastic cookware.