

## **KitchenAid® Artisan® Series 5 Quart Tilt-Head Stand Mixer**

### **Are there any other bowls that will fit the Artisan Stand Mixer?**

The following KitchenAid® Bowls are available (sold separately):

- 5 Quart Glass Bowl with Handle – KA Model #K5GB
- 5 Quart Hammered Glass Bowl with Handle – KA Model #K5GBF
- 5 Quart Frosted Glass Bowl with Handle – KA Model #K5GBH
- 5 Quart Ceramic Bowl with Handle – KA Model #KSMCB5
- 3 Quart Polished Stainless Steel Bowl – KA Model #KB3SS

### **What attachments can I use with the Artisan Stand Mixer?**

All hub powered KitchenAid® stand mixer attachments are designed to fit any KitchenAid® stand mixer, as they all feature an Attachment Power Hub that accepts over 10 attachments. With the versatile and easy to use attachments you can turn your stand mixer in the culinary center of your kitchen. Simply remove or flip-up the Hub cover, insert an attachment to quickly and easily grind meat, spiralize or sheet cut fruits and vegetables, make fresh pasta, mill grains and so much more.

### **What is the Flex Edge Beater and what does it do?**

The Flex Edge Beater reduces mixing time and the need to scrape ingredients down the side of the bowl when you're mixing with this beater, which features a flexible edge that thoroughly scrapes ingredients into the bowl. Dishwasher safe.

### **How will I know when to use the flex edge beater versus the flat beater with my recipe?**

The Flat and Flex Edge Beater are both great for any mix of ingredients, whether light or dense, for quick and thorough mixing. The Flex Edge Beater features a flexible edge that thoroughly scrapes ingredients into the bowl. This can reduce mixing time and the need to scrape ingredients down the side of the bowl when you're mixing with this beater.

### **Are the beaters dishwasher safe?**

The coated flat beater, flex edge beater and dough hook are dishwasher safe. Hand washing is recommended for the Wire Whip.

### **Are Instructions included?**

Yes – A Use & Care Guide is included.