



## USING YOUR COOKWARE GRIPS

Your Zakarian Cookware Grips are designed for use on the handles of Zakarian Cast Iron Pans and Dutch Ovens. This 4-piece set includes one grip for a 6-, 8- or 10-inch pan, one grip for a 12-inch pan and two Side Grips that can be used on the Zakarian Dutch Oven, 12x12 Grill Topper, and 12" All Purpose Pan.

Each Cookware Grip is made of heat-resistant silicone and provides a convenient non-slip handle for moving pots and pans on your stovetop with ease. To use, simply select the Grip that corresponds with the size of your cookware handle and slide the Grip over the handle before you begin cooking.

It is recommended to wait until your pot or pan has cooled completely before removing the Grip from the handle, as your cookware may still be hot. Use protective kitchen gloves when removing Cookware Grips.

Silicone Grips do not always have to be attached to the pan when cooking! They can simply be used as potholders to remove pans from the oven or stove.

**NOTE:** Cookware Grips are heat safe up to 425°F but may become hot after continued exposure to heat. Exercise caution and use protective kitchen gloves when handling the Cookware Grips, as they are NOT a cool-touch handle and will be hot when removing cookware from the oven or stovetop.

K52091

# COOKWARE GRIPS, 4-PIECE SET

## CARE & CLEANING

Zakarian Cookware Grips are dishwasher safe and can be cleaned with a non-abrasive cleaner and warm, soapy water. Harsh metal brushes or sponges may damage the silicone.

## WARRANTY

### DASH - 1 YEAR LIMITED WARRANTY

Your Zakarian by Dash product is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of the original purchase when utilized for normal and intended household use. Should any defect covered by the terms of the limited warranty be discovered within one (1) year, Dash will repair or replace the defective part. To process a warranty claim, contact Customer Support at 1-800-898-6970 for further assistance and instruction. A Customer Support agent will assist you by troubleshooting minor problems. If troubleshooting fails to fix the problem, a return authorization will be issued. Proof of purchase indicating the date and place of purchase is required and should accompany the return. You must also include your full name, shipping address, and telephone number. We are unable to ship returns to a PO box. Dash will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any or all of the necessary information. Freight costs must be prepaid by the purchaser.

Send all inquiries to [zakarian@bydash.com](mailto:zakarian@bydash.com).

There are no express warranties except as listed above.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER. DASH SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OR FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT REQUIRED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts. Therefore, the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Refurbished items or items not purchased through an authorized retailer are not eligible for warranty claims.



K52091\_OneSheeter\_20210510\_V3  
Made in China