

CE Electric 1-Stage Knife Sharpener

⚠ Notes:

Please note that changes or modifications of this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. QVC, INC. 1200 Wilson Drive West Chester, PA 19380.

(484) 701-1000



Owner's Manual

CE Electric 1-Stage Knife Sharpener
Model: K55868

**FOR HOUSEHOLD
USE ONLY**

CE Electric 1-Stage Knife Sharpener

ADAPTER INSTRUCTION MANUAL :

USER'S MANUAL

IMPORTANT SAFETY INSTRUCTIONS — SAVE THESE INSTRUCTIONS
"DANGER-TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK,
CAREFULLY FOLLOW THESE INSTRUCTIONS".

Class 2 Power Supply

Please read the following information carefully.

1. The maximum ambient temperature should not exceed 35°C.
2. The adaptor shall be installed according to specification.
The current of load and output power shall not exceed the following value:
Model: HCX1201-1800600U
Input: 100-240V ~ 50-60Hz 0.5A
Output: 18V === 0.6A
3. Risk of Electric Shock. For indoor use only. Dry location use only.
4. This Switching Adapter is not intended to be repaired by service personal in case of failure or component defect.
5. The main plug is used as disconnect device, the socket-outlet should be near the Switching Adapter and it should be easily accessible.
6. This product must not be disposed together with the domestic waste.
This product has to be disposed at an authorized place for recycling of electrical and electronic appliances.
By collecting and recycling waste, you help save natural resources, and make sure the product is disposed in an environmental friendly and healthy way.
7. For connection to a supply not in the U.S.A, use an attachment plug adapter of the proper configuration for the power outlet, if needed
8. Class 2 Power Supply

ATTENTION
UTILISATION DANS UN ENDROIT SEC SEULEMENT
RISQUES D'INCENDIE OU DE CHOC ELECTRIQUE
VOIR LE MANUEL AVANT UTILISATION

CAUTION
DRY LOCATION USE ONLY RISK OF ELECTRIC SHOCK
SEE MANUAL FOR VOLTAGE CONVERSION

Name: GUANGDONG HUACHUANGXINGPOWER SUPPLY CO.,LTD.
Address: NO.27 FUDONG ROAD,DONGFENG VILLAGE, LELIUSTREET,
SHUNDE DISTRICT, 528000 FOSHAN CITY, GUANGDONG PROVINCE

CE Electric 1-Stage Knife Sharpener

! IMPORTANT SAFEGUARDS:

1. Read and understand the instruction manual before use.
2. Do not remove the housing during use.
3. Extreme caution must be taken when sharpening.
4. Do not put the product near fire.
5. Switch off and disconnect the adapter before cleaning.
6. Do not immerse the power cord or body in water.
7. Do not disassemble the product yourself, or it may cause a malfunction.
8. Disconnect power supply when not in use.
9. When cleaning the product, wipe the surface with a soft cloth.
10. Do not cover the top of the product during use.
11. Do not let water get into the product when cleaning.
12. It may cause a slight smell during sharpening a knife. It is not a malfunction.
13. Please use the DC adapter (18V) included.
14. Place the product on a flat and dry surface.
15. Please clean the knife before sharpening.
16. No lubricant or abrasive is needed for sharpening.
17. It is not suitable for sharpening serrated or ceramic knives.

How to use:



1. Switch it Off position, Insert the adapter power connector into the knife sharpener. Plug adapter wall plug into an 120V AC Power Outlet.



2. Power on the knife sharpener by switching it in ON position.



3. Place the knife blade edge in the L groove. Pull it back in smooth motion slowly. Lift and repeat in R groove. Do not move it back and forth.

! Attention: DO NOT TO PULL BACK AND FORTH,Ceramic knives are not suitable.

Specifications:

Name : CE Electric 1-Stage Knife Sharpener
Model : K55868
Voltage/Power : DC 18V 10W
MADE IN CHINA



cook's essentials®