



Extra-Large French Door Digital Air Fry Oven with Grill

Quick Start Guide / Cooking Chart

Grill Chart Notes:

- Preheat Grill Plate prior to use.
- To preheat the Grill Plate, place it in the oven. Select grill function, set time and temperature and then press Start to begin preheating.
- Once preheat is complete, place food on the Grill Plate. Press Start to begin cook timer.
- Ensure Grill Plate is placed on lowest rack position for optimal performance.
- Avoid pulling rack with Grill Plate more than 2/3 out of the oven and use oven mitts.
- See Instruction Booklet section “Using the Grill Function” for details.
- Chart times are based on raw, unfrozen foods. All foods should be fully defrosted before grilling for optimal performance.

CAUTION: Always ensure internal food temperatures meet FDA guidelines for safety.

Grilling Chart

Food	Weight	Cook Time
Pork Chops	12 oz	12-15 minutes
Boneless Chicken Breast (Whole)	2.5 lbs	20-25 minutes
Hot Dogs	(6x) 2 oz hot dogs	10-12 minutes
Hamburgers	(5x) 5 oz burgers	8-10 minutes
Salmon	20 oz	9-11 minutes
Zucchini	12 oz sliced	9-11 minutes

Air Fry Notes:

- Arrange food evenly in the air fry basket.
- For foods with high amounts of fat or grease, place the baking pan below the air fry basket or wire rack during cooking.

Air Fry Chart

Food	Weight	Function	Temperature (°F)	Time (min)	Oil?
Potatoes					
Hand-Cut Fries	1.5 lb	AIR FRY	450 degrees	30-35 min	Yes
Hand-Cut Sweet Potato Fries	1.5 lb	AIR FRY	450 degrees	15-20 min	Yes
Frozen Hash Brown	1.5 lb	AIR FRY	450 degrees	15-20 min	No
Frozen Fries (Thick Cut)	1.5 lb	AIR FRY	450 degrees	20-25 min	No
Frozen Fries (Thin Cut)	1.5 lb	AIR FRY	450 degrees	15-20 min	No
Potato Skin	1 lb	AIR FRY	450 degrees	10 min	Yes
Meat/Poultry/Fish					
Chicken Wings	1.5 lb	AIR FRY	450 degrees	20-25 min	No
Steak	1 lb	AIR FRY	450 degrees	10-12 min	Yes
Pork Chops	1.5 oz	AIR FRY	425 degrees	20 min	Yes
Hamburger	1 lb	AIR FRY	425 degrees	12-15 min	No
Chicken Breast	1 lb	AIR FRY	400 degrees	20-25 min	Yes
Breaded Chicken Breast	1 lb	AIR FRY	400 degrees	20-25 min	No
Breaded Fish	1 lb	AIR FRY	400 degrees	12-15 min	No
Bacon	0.5 lb	AIR FRY	425 degrees	12-15 min	No
Salmon	1-1.5 lb	AIR FRY	450 degrees	15 min	No
Snacks					
Frozen Chicken Nuggets	1.5 lb	AIR FRY	425 degrees	15-20 min	No
Frozen Mozzarella Sticks	0.5 lb	AIR FRY	450 degrees	10-15 min	No
Frozen Onion Rings	1.5 lb	AIR FRY	450 degrees	10-15 min	No
Vegetable					
Tender Stem Broccoli	1 lb	AIR FRY	400 degrees	10-15 min	Yes
Asparagus	1 lb	AIR FRY	400 degrees	8 min	Yes
Brussel Sprouts	1 lb	AIR FRY	400 degrees	12-15 min	Yes
Mushroom	1 lb	AIR FRY	400 degrees	8-10 min	Yes
Fresh Mixed Vegetables	1.5 lb	AIR FRY	400 degrees	15-20 min	Yes

NOTE: Cook times are estimates and may vary based on food type and preparation.

TSSTTVFDDAF-XX_22EQSG1_GCDS-JC

NWL0001408126