



USING YOUR MAGNETIC SILICONE TRIVETS

The Zakarian 4-Piece Magnetic Silicone Trivet Set contains two 4.5” trivets and two 6” trivets.

To use your Magnetic Silicone Trivets, simply place on a surface and rest the pot you wish to use on top of the Silicone Trivet. The magnets should cause the Silicone Trivet to attach automatically to the bottom of the pot. The Silicone Trivets come in different sizes. For best results, use the size that most closely corresponds to the base of your pan.

NOTE:

- Magnetic Silicone Trivets will not work with pans that are solely aluminum.
- Silicone Trivets can be heated up to 425°F. Silicone Trivets are NOT intended for use in the microwave or oven.
- Be careful when resting hot pans and Silicone Trivets on varnished wood surfaces, as heated trivets and pans may damage the varnish.
- It is best to wait until the pan has cooled completely before removing the Magnetic Silicone Trivet from the base, as the pan and trivet may still be hot. Use protective kitchen gloves when removing the Magnetic Silicone Trivets.
- Trivets can also be used as a grip for hot pan handles and lid knobs. Exercise caution when using the trivets to move hot cookware.
- The raised surface of the trivet is also designed for use as a spoon rest or small drying mat.

CARE & CLEANING

Magnetic Silicone Trivets are dishwasher safe and can be cleaned with a non-abrasive cleaner and warm, soapy water. Harsh metal brushes or sponges may damage the silicone.

K49745

4-PIECE MAGNETIC SILICONE TRIVET

WARRANTY

DASH - 1 YEAR LIMITED WARRANTY

Your Zakarian by Dash product is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of the original purchase when utilized for normal and intended household use. Should any defect covered by the terms of the limited warranty be discovered within one (1) year, Dash will repair or replace the defective part. To process a warranty claim, contact Customer Support at 1-800-898-6970 for further assistance and instruction. A Customer Support agent will assist you by troubleshooting minor problems. If troubleshooting fails to fix the problem, a return authorization will be issued. Proof of purchase indicating the date and place of purchase is required and should accompany the return. You must also include your full name, shipping address, and telephone number. We are unable to ship returns to a PO box. Dash will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any or all of the necessary information. Freight costs must be prepaid by the purchaser.

Send all inquiries to zakarian@bydash.com.

There are no express warranties except as listed above.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER. DASH SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OR FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT REQUIRED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts. Therefore, the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Refurbished items or items not purchased through an authorized retailer are not eligible for warranty claims.



K49745_OneSheeter_08222019_V2
Made in China