

TO USE EDGEKEEPER® SHARPENER



TO USE EDGEKEEPER® SHARPENER:

Step 1: Remove shears from sleeve and open the blades.

Step 2: Place the bottom blade fully through the sharpener unit, and while applying even pressure, close the blades together.

Step 3: Repeat until desired sharpness is achieved.

HAND-WASHING

For all fine cutlery, best results are obtained by hand-washing. Wash with warm, soapy water, and rinse thoroughly. Dry immediately. For safety, wash each item separately, not with other cutlery or utensils.

edgekeeper®



SABATIER

IMPORTANT:

Use caution when opening package and handling shears. Sabatier® shears are extremely sharp. Keep sharp shears out of the reach of children.

LIFETIME LIMITED WARRANTY

This fine product is warranted to be free from defects in material and workmanship. Any piece found to be defective under normal use and care will be repaired or replaced at no charge with the same item or an item of equal or better value. Individual pieces should be returned postage prepaid to: Sabatier, c/o Lifetime Brands, Inc., Customer Service Department, P.O. Box 9750, Trenton, NJ 08650-1750. You may have other rights, which vary from state to state.

The trademarks ® and ™ and logos appearing herein are the property of Lifetime Brands, Inc., and/or their respective owners. © 2024. All rights reserved.

Edgekeeper® is a registered trademark of Lifetime Brands, Inc.
U.S. PATENT NO. D789,077 S

STYLE # 5318862

Manufactured under license
by Lifetime Brands, Inc.
1000 Stewart Avenue
Garden City, NY 11530
Made in China



SABATIER

3 PIECE SHEARS SET

SET INCLUDES:
10-IN-1 MULTIPURPOSE SHEARS
WITH MAGNETIC SHARPENING HOLDER


5-IN-1 ULTIMATE SHEARS
WITH BUILT-IN SHARPENING SLEEVE

BENT SHEARS
WITH BLADE COVER



edgekeeper®

10-IN-1 MULTIPURPOSE SHEARS WITH MAGNETIC SHARPENING HOLDER



5-IN-1 ULTIMATE SHEARS WITH BUILT-IN SHARPENING SLEEVE



BENT SHEARS WITH BLADE COVER

