



USE & CARE

Ceramic Microwave Bacon Cooker

The Chefologist Ceramic Bacon Cooker with our high-quality ceramic cooker is heat-resistant and food-safe for delicious, crispy results every time! The unique splatter-proof design ensures a mess-free cooking experience for bacon lovers! Heat Safe to 350F and Dishwasher safe, no more messy microwave ovens, say goodbye to paper towels and hello to easy clean-up! It is the perfect solution for cooking crispy, delicious bacon in minutes! The package comes with everything you need to cook yummy crispy bacon (1 ceramic grease collector, 1 ceramic holder, 1 silicone lid, and 1 tong).

1. Place the ceramic holder on the grease collector, then place the strips of bacon on the holder (6 strips - image 1 below)
2. Cover with the silicone lid and be sure that lid is slightly off center to allow the hole in the edge of the lid to act as a steam vent (picture 3 below). This will allow the steam to escape during the cooking process and prevent the lid from popping off. Place the cooker in the microwave. Allowing for 1 minute per each piece of bacon, cook on high (6-7 minutes). Cook longer if you want a crispier result or if you are cooking thick cut bacon.
3. Using oven mitts, remove the bacon cooker from the microwave and remove the cooked bacon with the provided tongs.

With its simple design and dishwasher-safe feature, you'll be enjoying delicious, yummy crispy, grease-free bacon in no time.



Make sure the lid is centered on the cannister



Made in China.

Visit us online at <https://thechefologist.com>