



FIND WHAT YOU NEED, WHEN YOU NEED IT



**STATEMENT:**  
Hereby, HButler Pty Ltd, declares that Orbit is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

## What is Orbit?

Orbit is an anodised aluminium Bluetooth device, with an easy to use app that finds everyday items with the tap of a button. If out of range, you can check the map for your Orbits last known location and time. You can also find your phone with Orbit. Press Orbit to make your phone ring - even when it's silent.

With Orbit, you can takes selfies. No need for a selfie stick, all you need to do is set your smartphone camera where you want it and with a click of the Orbit button you can take selfies to your hearts content.

For the full Orbit Manual please visit: [findorbit.com/help](http://findorbit.com/help)


## Replacing the battery




1. To replace the battery, enclose the Orbit in between the 2 battery opening tools.



2. Twist the top battery tool anti-clockwise to open.



3. Open the Orbit and detach old battery from inside.



4. Place the new battery with the (+) symbol facing down.



5. Push the top and bottom Orbit shell together. Place the Orbit in between the opening tool. Twist clockwise to lock Orbit.

## Mobile Device Compatibility

ORBIT syncs with the following devices that support Bluetooth 4.0:

### iOS:

iPhone 4S and later

### Android:

Android 4.4 and above

## Downloading the App

Install the ORBIT app by downloading "ORBIT - Find your keys, Find your phone, Take a selfie" on the **App Store** or **Google play**.



Open the app and **press allow** to 'find your location'. Please **ensure Bluetooth is turned on** for the app to connect to ORBIT.

## How to...

### How to activate your ORBIT for first time activation


Press and hold the button on your Orbit for 5 seconds. You should hear a beep



1. Location of the button on your ORBIT

### How to find your keys with your phone

Press "Find Orbit" to make your Orbit ring



2. The app layout displaying the last location screen

### How to find your phone with your keys

Press the button on your Orbit to make your phone ring

### How to use your ORBIT as a selfie

Select the camera icon then Press the Orbit button to take a photo

### If your Orbit is out of range its last location is shown on the map

## Using the app

### 1. Device List

Press the side button of your ORBIT for searching. Tap device list icon then tap (+) icon. 'ORBIT device' will appear.

### 2. Settings

Tap here to open Advanced Settings

### 3. Camera

Tap here to activate camera. Selfie with ORBIT can only be used with App Camera

### 4. Your Orbits Location

Shows your Orbit location on the map

### 5. Add an ORBIT

Adds a new Orbit device to your list

### 6. Expand List

Expand to see all your Orbits in the list

### 7. More Options

More Options for your Orbit

### 8. Tap here to find your ORBIT



# IMPORTANT SAFETY WARNINGS

## General Precautions

- ORBIT is not a toy
- Do not attempt to tamper with/modify/disassemble ORBIT
- Do not expose ORBIT to abrasive materials
- Do not place ORBIT near open flames
- Review ORBIT Specifications and other Information > Environmental Conditions and do not expose ORBIT beyond operating temperatures
- ORBIT’s metal body conducts temperature effectively, avoid contact when left in extreme temperatures
- ORBIT’s edges can be sharp, handle with care

Read, follow and keep this user manual and all safety instructions. Improper installation, use or disposal of ORBIT could be hazardous to your health and put others at risk.

## Child Safety

ORBIT contains small parts, which can be a choking hazard. Please keep away from young children. If battery is swallowed, immediately seek medical help as serious injury may occur.

## Battery Precautions

- Follow battery replacement instructions provided with this guide
- Do not charge, short, disassemble, deform or heat batteries
- Do not throw batteries into fire
- Avoid mixed use of batteries, e.g. new, used or different types
- Keep batteries away from direct sunlight, high temperature and humidity
- Keep batteries out of reach of small children. Should a child swallow a battery, consult a physician immediately.

# TECH DETAILS

## Orbit Technology and Tech Details:

Orbit uses Bluetooth Low Energy (BLE) technology to help you locate your items. While Bluetooth technology is a wireless technology, there are significant differences between Bluetooth, Wi-Fi, and GPS technology. Orbit’s Bluetooth range is up to 100 ft. Bluetooth is most effective at the 30ft range, depending on the environment. Learn more about Bluetooth at <http://www.bluetooth.com/> Battery: CR2025 Battery included. Product Battery Life: 8765 Hours.

## How many Orbit devices can be paired to my phone or tablet?

Apple iOS devices can pair up to 6 Orbit devices at a time. Android devices can pair anywhere between 1-3 depending on the manufacturer and the operating system version.

The users manual or instruction manual shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: This device has been tested and found to comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1.this device may not cause harmful interference, and
- 2.this device must accept any interference, receive including interference that may cause undesired operation.

# SPECIFICATIONS

## Battery

ORBIT is powered by a CR2025 coin cell battery (included). It lasts 6 months with normal use and 12 months when on standby. When you see this low battery indicator on the upper left hand corner after you sync ORBIT to the app, you have less than one week to replace the battery. We recommend using the same brand (or one with equivalent quality), which should give you the estimated battery life. Please refer to page 3 on how to replace the battery.

## Best practices to maximise ORBIT’s battery life:

- Keep the app up to date
- Resist unnecessary tapping of ORBIT as a party trick

Operating temperature range: -22° to 14° F [-30° to 60° C]

## Life

The life span of ORBIT is 4 months if used often, and 12 months on Standby. After this time frame you will need to change the battery.

## Size & Weight

Dimensions:  
Diameter: 34mm/ 1.33" Weight:  
Thickness: 9mm/ 0.35" 20g/ 0.70oz/ 0.04 lb

## Splashproof

ORBIT is splashproof. Suitable for dishwashing, splashing and swimming in shallows waters, not snorkeling or diving.

## To maintain water resistance:

- Install the back cover correctly
- Do not tamper with the back cover when it is still submerged in liquid
- Avoid prolonged exposure to salt water or other chemicals, e.g. detergent, chlorine
- Avoid moving ORBIT in and out of contrasting extreme atmospheres; saunas, steam rooms, hot tubs and hot showers could distort the sealing gasket
- Avoid opening the back cover unnecessarily
- When opening the back cover to replace the battery, avoid touching the gasket
- Never leave ORBIT open for more than a few hours; a dry gasket will cause the seal to fail

## Environmental Conditions

Operating temperature: -4° to 122° F [-20° to 50° C]

## Return Policy and Warranty


ORBIT has a Six Months Limited Warranty - for more information, visit: <https://hbutler.zendesks.com/hc/en-us>

## Disposal and Recycling

Please kindly be aware that it is the consumer’s responsibility to properly dispose and recycle ORBIT and accompanying components. Do not dispose of ORBIT with common household waste, the ORBIT unit is considered electronic waste and should be disposed of at your local electronic equipment collection facility.

For more information, please contact your local electronic equipment waste management authority or the retailer where you bought the product.

When discarding batteries, insulate the + and - faces of batteries with insulating or any kind of non-conductive tape (see diagram). If improperly disposed, lithium batteries may short, causing them to become hot, burst or ignite.



\*For complete Panasonic CR2025 battery warning and disposal information, please refer to original source: <http://industrial.panasonic.com/www-data/pdf/AAA4000/AAA4000PE15.pdf>

# LIMITED WARRANTY

IMPORTANT INFORMATION ABOUT YOUR RIGHTS AND OBLIGATIONS, AS WELL AS LIMITATIONS AND EXCLUSIONS THAT MAY APPLY TO YOU.

## YOUR RIGHTS AND THIS LIMITED WARRANTY

This Limited Warranty gives you specific legal rights. You may also have other legal rights that vary by state, province or jurisdiction. The disclaimers, exclusions, and limitations of liability under this Limited Warranty will not apply to the extent prohibited by applicable law. For a full description of your legal rights you should refer to the laws applicable in your jurisdiction and you may wish to contact a relevant consumer advisory service.

## WHAT THIS LIMITED WARRANTY COVERS; PERIOD OF COVERAGE

ORBIT by HButler warrants that your ORBIT product will be free from defects in materials and workmanship for a period of one (1) year from the date of delivery following the original retail purchase (the "Warranty Period").

If a defect in the Product arises within the Warranty Period, ORBIT will, at its sole option and subject to applicable laws: (a) repair or replace it with a new or refurbished product or component; or (b) refund the original purchase price upon return of the defective Product. If the Product or a component incorporated within it is no longer available, ORBIT may replace the Product with a similar product of similar function, at ORBIT’s sole discretion.

## WARRANTY CONDITIONS; HOW TO GET SERVICE IF YOU WANT TO CLAIM UNDER THIS LIMITED WARRANTY

Before being able to claim under this Limited Warranty, the owner of the Product must notify ORBIT of the intention to claim by visiting [www.findorbbit.com/help](http://www.findorbbit.com/help), e-mailing [customerservice@hbutler.com](mailto:customerservice@hbutler.com) or calling our toll free number 888-268-1499 during the Warranty Period and providing a description of the alleged failure. ORBIT will have no warranty obligations with respect to a returned Product if it determines, in its reasonable discretion after examination

of the returned Product, that the Product is an Ineligible Product (defined below). ORBIT will bear all costs of return shipping to owner, except with respect to any Ineligible Product, for which owner will bear all shipping costs.

For warranty claims on items purchased at authorized retail locations, you may return your ORBIT to the point of purchase.

## WHAT THIS LIMITED WARRANTY DOES NOT COVER

This warranty does not cover the following (collectively "Ineligible Products"): Products marked as "sample"; or Products that have been subject to: (a) modifications, alterations, tampering, abuse, accident; (b) unauthorized modification or improper maintenance or repairs; (c) purchase from unauthorized resellers; (d) where the Product is used with a jailbroken or rooted mobile device; (e) handling, storage, installation, testing, or use not in accordance with ORBIT’s User’s Guide or other instructions provided by ORBIT; (f) other causes beyond our reasonable control.

DISCLAIMER OF WARRANTIES EXCEPT AS STATED ABOVE IN THIS LIMITED WARRANTY, AND TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, ORBIT DISCLAIMS ALL EXPRESS, IMPLIED, AND STATUTORY WARRANTIES AND CONDITIONS WITH RESPECT TO THE PRODUCT, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, ORBIT ALSO LIMITS THE DURATION OF ANY IMPLIED WARRANTIES OR CONDITIONS TO THE DURATION OF THIS LIMITED WARRANTY.

# RETURNS

We only replace items if they are defective or damaged. If you need to exchange an item, send us an email at [customerservice@hbutler.co](mailto:customerservice@hbutler.co) and send your item to: HButler , PO Box 600, One Corporate Drive, Grantsville MD 21536 USA.

Returned merchandise must be accompanied by the original sales receipt.

## Returning an order

Please email us at [customerservice@hbutler.co](mailto:customerservice@hbutler.co) with your name, shipping address, invoice details and reason for the return.

To return your product, mail it to: HButler , PO Box 600, One Corporate Drive, Grantsville MD 21536 USA.

You are responsible for paying return shipping costs. Shipping costs are non-refundable. Depending on where you live, the time it may take for your exchanged product to reach you, may vary.

If you are shipping an item over \$75, you should consider using a trackable shipping service or purchasing shipping insurance to guarantee we receive your returned item. To complete your return, please ensure receipt or proof of purchase is provided.

## Refunds (if applicable)

Once your return is received and inspected, we will send you an email to notify you that we have received the returned item. We will also notify you of the approval or rejection of your refund.

Approved refunds will be processed and a credit will automatically be applied to your credit card or original method of payment, within a few days.

## Sale items (if applicable)

Only regular priced items may be refunded. Unfortunately sale items cannot be refunded.