

RECOIL AUTOMATIC CORD WINDERS



CUSTOMER SUPPORT

1-866-660-8661

support@recoilwinders.com

CONGRATULATIONS ON PURCHASING RECOIL CORD WINDERS!

Now you can instantly organize your personal electronic cords — chargers, USB cords, headphones and more, and eliminate the frustration of cord clutter from your life.

Also included is the Recoil Rack, which gathers all of your winders into one tangle-free and organized system.

**THANKS FOR CHOOSING RECOIL
AUTOMATIC CORD WINDERS.**

LIFE UNTANGLED


Please take a few minutes to read the enclosed instructions and learn how to use your RECOIL CORD WINDER.

Get **USER TIPS** and **WARRANTY INFORMATION** at:


recoilwinders.com/user-tips

Or scan the QR tag below.




WIND YOUR CORDS


1. Fold the cord in half. Place the bend on the hook.




2. Pull straight down to release the white button behind the hook. This will unlock the winder and let the cord wind.



If winding headphones, make sure the jack end is longer than the earbuds.

**UNWIND
YOUR
CORDS**

1. Grab the cord and pull upward until cord is fully extended.



2. When the cord is unwound, relax tension, letting the cord slide off the white button behind the hook. The winder will lock.

TIP #1: Always pull on the cord itself, not the cord ends.

TIP #2: Depending on the type of cord material you may need to play with the angle to achieve the lock.

**HOW TO USE
THE RECOIL RACK**

Snap your Recoil Winders into the the **RECOIL RACK** to lock in and organize your winders.