


TotalBoost Mini™

Troubleshooting


If the Switch is more difficult to push once an adapter is installed, try doing this to make it easier:



Hold the TotalBoost Mini as shown in the figure and use your thumb to push the Switch and dislodge the adapter.

Tip: Try using your nail for extra leverage.

If the adapter gets stuck in a device when unplugging, try doing this:



Re-insert the adapter into the TotalBoost Mini and apply pressure on the Switch while disconnecting from the device. This will hold the adapter in place.

LIMITLESS™



Scan the code
to watch a
tutorial video

Not sure which adapter you need?

Refer to the list below:



Type-C

Samsung, Microsoft, Google, LG, Huawei, and More



Lightning

iPhones & Most Apple Devices



Micro

Tracphones, Speakers, Cameras, Power Banks, & More

Need more help? Contact us!



(855) 843-4828



Support@LimitlessInnovations.com



LimitlessInnovations.com/Support