

LIMITLESS™

Elite 15,000mAh Power Bank

AC Plug, Built-In Cable & Retractable Cable, Digital Display, & Wireless Charging

Quick Start Guide



WHAT'S INCLUDED

- (1) Elite 15,000mAh Power Bank
- (1) Faux Leather Carrying Case
- (1) 36" Type-C to USB Charging Cable

COMPONENTS

1. Digital LCD Display
2. Wireless Charger
3. Slide-Out Phone Holder
4. Built-In Lightning® Cable
5. Flashlight
6. USB Charging Ports
7. Flashlight Power Button
8. Retractable AC Plug
9. Magnetic Kickstand
10. Type-C to Micro Adapter
11. Retractable 24" Type-C Cable

Scan to learn more about using the features of your Elite 15,000mAh Power Bank



CHARGING & RECHARGING

Using the Power Bank

Select your compatible charging method from below and connect the Power Bank to a device. The device will automatically begin to charge.

- Built-In Cables
- Type-C to Micro Adapter
- USB Port
- Wireless Charger (see below for placement)



If Type-C or Lightning®, use one of the built-in cables.

1. Locate the appropriate cable by removing it from the built-in cable storage.
2. Plug the Cable Connector into the charging port of the device.

Extending / Retracting the Type-C Cable

Extend the cable and connect the Type-C end to a compatible device. The device will begin to charge. The Retractable Cable can stop at any point and then pull again to retract. When not in use, ensure the cable is fully retracted to prevent damage or tangling.

Note: Do not overextend the cable. Doing so may damage the Elite 15,000mAh Power Bank.

If Micro, use the Type-C to Micro Adapter.

1. Locate the Type-C Built-In Cable.
2. Plug the Type-C end directly into the Micro Adapter opening.
3. Pull the Micro Adapter out once connected via Type-C.
4. Once the Adapter is installed, plug it into the charging port of the device. The device will begin to charge.



NOTE: When finished, remove the Micro Adapter from the Type-C Cable, then push the Adapter back into the storage slot.

If Charging via USB Ports, Plug a compatible USB cable into one of the two USB-A ports, and plug the opposite end into a device.

NOTE: You'll see a green icon when a device capable of fast-charging is connected to the Power Bank using the integrated cables or the Wireless Charger. Keep in mind that some devices might not display this green icon, but they will still receive the fastest charging speed the power bank can deliver and the device can accept.

If Charging via USB Ports, Plug a compatible USB cable into one of the two USB-A ports, and plug the opposite end into a device.

Recharging the Power Bank

Option 1: Extend the AC Plug & connect to a wall outlet.

Option 2: Plug the included 36" Type-C to USB Charging Cable into the Type-C Port. Plug the opposite end of the Charging Cable into a USB power source (not included).

Option 3: Plug the Built-In Type-C Charging Cable into a Type-C power source (not included).

The Digital Battery Level Indicator will blink while charging until it reaches 100%. **NOTE:** Only the second digit blinks while charging the Power Bank.



Checking the Battery Level

Press the Power Button to show the current battery capacity on the Digital LCD Display.

FLASHLIGHT

1. Press and hold the Power Button to turn the Flashlight on.
2. Continuously click the Power Button to scan through the modes, or press and hold to shut off the Flashlight.

INNOVATIVE GaN TECHNOLOGY

Compared with silicon chargers, GaN chargers require fewer components. GaN chargers are physically smaller and conduct higher voltages. GaN chargers are more efficient in transferring current and conserving energy. Conserved energy enables a better flow to the charging device, resulting in quicker charge times.

PHONE HOLDER & KICKSTAND

Open the Magnetic Kickstand using the inset on the back of the Power Bank. Slide out the Phone Holder on the bottom.



Add a device horizontally or vertically. See the next page for further instructions on charging options.


Wireless Charging

Prop the device vertically on the Phone Holder to utilize the Wireless Charger.



Charging Cable

Prop the device horizontally on the Phone Holder. Connect a compatible built-in cable or use your own cable with the USB Port.



COMPATIBILITY

Type-C: Galaxy S phones: Galaxy S23, S23+, S23 Ultra, S22, S22+, S22 Ultra, S21 5G, S21+ 5G, S21 Ultra 5G, S20 5G, S20+ 5G, S20 Ultra 5G, S10e, S10, S10+, S10 5G, S8, S8+, S9, S9+ | Galaxy Fold phones: Z Fold, Z Fold2, Z Fold3, Z Fold4, Z Flip, Z Flip 5G, Z Flip3 5G, and Z Flip4 | Galaxy Note phones: Note8, Note9, Note10, Note10+, Note10+ 5G, Note 20 5G, and Note20 Ultra 5G | Galaxy A phones: A03s, A10e, A20, A50, A02, A12, A13, A14 5G, A23 5G, A32 5G, A42 5G, A71, A51, A21, A11, A01, A13 5G, A52 5G, A53 5G, and A54 5G | Apple: iPhone 15 and newer, iPads 2018 and newer, AirPods Pro 2nd gen., and AirPods Max.

Lightning*: iPhones: iPhone 5, iPhone 6, iPhone 7, iPhone 8, iPhone X, iPhone 11, iPhone 12, iPhone 13, iPhone 14, and various SE models | iPads: iPad (4th through 9th gen.), iPad mini (1st through 5th gen.), iPad Air (1st through 3rd gen.), 1st and 2nd gen. of the 12.9-inch iPad Pro, and the 10.5 inch iPad Pro | iPods: iPod nano (7th gen.) and iPod touch (5th through 7th gen.) | Apple Accessories: 1st gen. Apple Pencil, 1st gen. AirPods, AirPods Pro, and earlier versions of Apple's Magic Keyboard, Magic Mouse, and Magic Trackpad.

Micro: Cameras, Gaming Controllers, Bluetooth Speakers, MP3 Players, Navigation Systems, and older Android Phones and Tablets.

Wireless Charging: Apple: iPhone 8 and newer, AirPods | Samsung: S6 and newer | Motorola: Droid, Moto, Edge+ | LG: G2 and newer | Lumia 950 and newer | Sony: Xperia Z3V and newer.

TECH SPECS

Model: LIM-E15KPB-XXX
Battery Capacity: 15,000mAh | 57.75Wh
Recharging Time (From 0%):
Using Built-In AC Plug: 5-6 Hours
Using Built-In Type-C Charging Cable and PD 20W Wall Charger: 5-6 Hours
Using included USB-A to Type C Cable: 7-8 Hours

AC Input: 110-240V | 50/60Hz | 0.5A
GaN Technology
USB Outputs: 5V==3A | 15W
Type-C Built-In Cable Input: 5V==3A | 9V==2A | 12V==1.5A | PD 18W
Type-C Built-In Cable Output: 5V==3A | 9V==2.22A | 12V==1.67A | PD 20W
Lightning* Cable Output: 5V==2.4A | 9V==2A | 12V==1.5A | QC 18W
Wireless Charging Output: 15W | 7.5W | 5W

Temperature Range (Operation):
32°-113°F (0°-45°C)

Flashlight: 25 Lumens | High & S.O.S.

Dimensions: 5.96" x 3.15" x 1.20"
Weight: 13.44oz (0.84lbs)

WAIVER & RELEASE

By using the Limitless Elite 15,000mAh Power Bank, you hereby agree that Limitless Innovations, Inc., an Illinois corporation and its affiliates ("Limitless") shall have no liability for any losses associated with property damage, personal injury or loss of life that are incurred by you or by any third party in connection with or relating in any manner whatsoever to your use of the Limitless Elite 15,000mAh Power Bank. By using the Limitless Elite 15,000mAh Power Bank, you hereby agree at all times to comply fully with all safety warnings, operating instructions and general safety information in this user manual. By using the Limitless Elite 15,000mAh Power Bank, you further agree to hold harmless Limitless, (and Limitless' officers, directors, shareholders and employees) in connection with any losses sustained by you (including, without limitation, losses arising in whole or in part from property damage, personal injury or loss of life) relating in any manner whatsoever to your use of the Limitless Elite 15,000mAh Power Banks.

WARNINGS

- The Elite 15,000mAh Power Bank is **NOT** a toy and should be kept away from children.
- Do **NOT** use the Elite 15,000mAh Power Bank near a magnetic or electric field.
- Keep the Elite 15,000mAh Power Bank in a cool and dry place away from heat sources, moisture, and dust. Avoid leaving the device in places with high temperatures such as cars parked under the sun.
- Do **NOT** use the Elite 15,000mAh Power Bank if it has been damaged and/or modified.
- Do **NOT** submerge the Elite 15,000mAh Power Bank or its accessories in water.
- Do **NOT** insert any foreign objects into the USB output port or joining terminals of the device. Short circuits may present risks of excessive heat, fire or explosion.
- Be cautious of drops, bumps, abrasions, or other impacts to the Elite 15,000mAh Power Bank. If there is any damage to the device such as dents, punctures, tears, deformities, or corrosion due to any cause, discontinue use. Contact Limitless Innovations or dispose of it in accordance to state and local guidelines.
- Do **NOT** attempt to disassemble, repair, or open the Elite 15,000mAh Power Bank or its accessories in any way.
- **CAUTION:** Risk of fire and burns. Do **NOT** open, crush, heat above 140° F (60° C) or incinerate.
- Do **NOT** use at an altitude higher than 6,562 feet (2,000 meters).
- If the Elite 15,000mAh Power Bank is not used for long periods of time, you should charge and discharge once every three months.
- When charging a device, the Elite 15,000mAh Power Bank may feel warm, this is a normal operating condition and should not be cause for concern.
- All products have gone through a thorough quality assurance inspection. If you find that your Elite 15,000mAh Power Bank is excessively hot, is emitting odor, is deformed, abraded, cut, or is experiencing or demonstrating an abnormal phenomenon, immediately stop all product use and contact Limitless Innovations.
- Batteries should be recycled or disposed of, as per state and local guidelines. Do not throw in the trash, as this can create a fire hazard.
- Do **NOT** apply excessive force on the Elite 15,000mAh Power Bank or dropping it: By doing so, it may damage the internal components of the device, and risk short circuiting the device when used.
- Do **NOT** overcharge the Elite 15,000mAh Power Bank as this may cause it to overheat and deplete efficiency. If the device becomes excessively hot during charging or discharging, unplug it from the power source or device immediately.
- Do **NOT** subject the Elite 15,000mAh Power Bank to harsh chemicals.
- Do **NOT** attempt to replace the battery as it is a non-serviceable part.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

AIR TRAVEL

- **You may carry the Elite 15,000mAh Power Bank on an airplane.**
- Do **NOT** travel with the Elite 15,000mAh Power Bank in your checked baggage.

For more information, visit:
<https://www.faa.gov/hazmat/packsafe#hazardousMaterial>

LIMITLESS™

Designed in USA. Made in China. All rights reserved. Limitless™ is a trademark of Limitless Innovations, Inc. Design and specifications subject to change without notice. Products may vary from images shown. All other trademarks included herein are property of their respective owners. Accessories sold separately.

LimitlessInnovations.com
Support@LimitlessInnovations.com
(855) 843-4828

Limitless Innovations, Inc.
4800 Metalmaster Way
McHenry, IL 60050

© Limitless Innovations, Inc.



@LimitlessInnovations



/LimitlessInnov



/LimitlessInnov



/LimitlessInnov



Limitless Innovations