

LIMITLESS™


3,000mAh Key Fob Power Bank

User Manual




WHAT'S INCLUDED

- A. (1) Limitless 3,000mAh Key Fob Power Bank
- B. (1) Carabiner Ring
- C. (1) 36" Type-C to USB Charging Cable
- D. (1) 4" Type-C to Micro Charging Cable



COMPONENTS

- 1. Built-in Type-C Cable (Output)
- 2. Carabiner Ring
- 3. Built-in Lightning® Cable (Output)
- 4. Battery Capacity Indicator Light
- 5. Flashlight Power Button
- 6. Flashlight
- 7. Type-C Charging Port (Input/Output)



Scan to learn more about using the features of your 3,000mAh Key Fob Power Bank.



HOW TO USE

Getting Started

The Power Bank will arrive with a partial charge. It is recommended to charge the battery to 100% before use.

Checking the Battery Level

Single press the Flashlight Power Button. The 4x LED Indicator Lights will illuminate indicating how much battery is left.

See table below.

LED INDICATOR LIGHT	CHARGE REMAINING
● ● ● ●	0%
○ ● ● ●	1-25%
○ ○ ● ●	26-50%
○ ○ ○ ●	51-75%
○ ○ ○ ○	76-100%

Recharging the Power Bank

1. Plug the Type-C end of the included 36" USB Cable into the Type-C Port and plug the opposite end into a USB charger (not included).

2. The Indicator Lights will begin to blink. Once all 4x Indicator Lights turn solid, the Power Bank is fully charged.

Using the Flashlight

- 1. Press & hold to turn on the Flashlight.
- 2. With the light on, single press to cycle through modes.
- 3. Press & hold to turn off the Flashlight.

Using the Power Bank

- 1. First, determine which charging connection the device is compatible with: Micro, Type-C, or Lightning®.
- 2. To charge a device via the Type-C Charging Port, connect a compatible Type-C cable. Once the device is connected, it will begin charging automatically.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

TECH SPECS

Model: LIM-3KKFPB-XXX
Battery Capacity: 3,000mAh | 11.1Wh
Recharging Time (From 0%): 2.5 Hours

Type-C Charging Port (Input/Output):
5V=2A | 10W
Built-In Cables Output: 5V=2A | 10W
Total Power Output: 5V=2A | 10W

Temperature Range (Operation) : -4°-104°F
Charging Operation Temperature: 32°-113°F
Discharging Operation Temperature:
-4°-140°F

Flashlight: 50 Lumens
2-Modes: High & S.O.S.

Dimensions: 3.12" x 2.09" x 0.59"
Weight: 0.185 lbs



WAIVER & RELEASE

By using the Limitless 3,000mAh Key Fob Power Bank, you hereby agree that Limitless Innovations, Inc., an Illinois corporation and its affiliates ("Limitless") shall have no liability for any losses associated with property damage, personal injury or loss of life that are incurred by you or by any third party in connection with or relating in any manner whatsoever to your use of the Limitless 3,000mAh Key Fob Power Bank. By using the Limitless 3,000mAh Key Fob Power Bank, you hereby agree at all times to comply fully with all safety warnings, operating instructions and general safety information in this user manual. By using the Limitless 3,000mAh Key Fob Power Bank, you further agree to hold harmless Limitless, (and Limitless' officers, directors, shareholders and employees) in connection with any losses sustained by you (including, without limitation, losses arising in whole or in part from property damage, personal injury or loss of life) relating in any manner whatsoever to your use of the Limitless 3,000mAh Key Fob Power Bank.

SAFETY WARNINGS

- The Limitless 3,000mAh Key Fob Power Bank is **NOT** a toy and should be kept away from children.
- Do **NOT** use the Limitless 3,000mAh Key Fob Power Bank near a magnetic or electric field.
- Keep the Limitless 3,000mAh Key Fob Power Bank in a cool and dry place away from heat sources, moisture, and dust. Avoid leaving the device in places with high temperatures such as cars parked under the sun.
- Do **NOT** use the Limitless 3,000mAh Key Fob Power Bank if it has been damaged and/or modified.
- Do **NOT** submerge the Limitless 3,000mAh Key Fob Power Bank or its accessories in water.
- Be cautious of drops, bumps, abrasions, or other impacts to the Limitless 3,000mAh Key Fob Power Bank. If there is any damage to the device such as dents, punctures, tears, deformities, or corrosion due to any cause, discontinue use. Contact Limitless Innovations or dispose of it in accordance to state and local guidelines.
- Do **NOT** attempt to replace the battery as it is a non-serviceable part.
- Do **NOT** attempt to disassemble, repair, or open the Limitless 3,000mAh Key Fob Power Bank or its accessories in any way.
- Do **NOT** subject the Limitless 3,000mAh Key Fob Power Bank to harsh chemicals.
- Do **NOT** use at an altitude higher than 6,562 feet (2,000 meters).
- Batteries should be recycled or disposed of, as per state and local guidelines.
- If the Limitless 3,000mAh Key Fob Power Bank is not used for long periods of time, you should charge and discharge once every three months.
- When charging a device, the Limitless 3,000mAh Key Fob Power Bank may feel warm, this is a normal operating condition and should not be cause for concern.
- All products have gone through a thorough quality assurance inspection. If you find that your Limitless 3,000mAh Key Fob Power Bank is excessively hot, is emitting odor, is deformed, abraded, cut, or is experiencing or demonstrating an abnormal phenomenon, immediately stop all product use and contact Limitless Innovations.
- Do **NOT** apply excessive force on the Limitless 3,000mAh Key Fob Power Bank or drop it: By doing so, it may damage the internal components of the device, and risk short circuiting the device when used.
- Do **NOT** overcharge the Limitless 3,000mAh Key Fob Power Bank as this may cause it to overheat and deplete efficiency. Follow the guidelines on the time required to fully charge your Limitless 3,000mAh Key Fob Power Bank. If the device becomes excessively hot during charging or discharging, unplug it from the power source or device immediately.
- **CAUTION:** Risk of fire and burns. Do **NOT** open, crush, heat above 140° F (60° C) or incinerate.
- **NEVER** store or transport where the port, adapter, or cable connectors can come in contact with loose metal objects. Contact with metal objects can cause a short circuit that can result in the battery overheating or catching fire.
- Do **NOT** insert any foreign objects into the port, adapter, or cable connector of the Limitless 3,000mAh Key Fob Power Bank.

LIMITLESS™

All rights reserved. Limitless 3,000mAh Key Fob Power Bank, 3,000mAh Key Fob Power Bank, and Limitless are trademarks of Limitless Innovations, Inc. Design and specifications subject to change without notice. Products may vary from images shown. Accessories sold separately. All other trademarks included herein are property of their respective owners.

LimitlessInnovations.com

Support@LimitlessInnovations.com
(855) 843-4828

© **Limitless Innovations, Inc.**

Designed in USA. Made in China.



@LimitlessInnovations



/LimitlessInnov



/LimitlessInnov



/LimitlessInnov



Limitless Innovations