




QUICK SET-UP GUIDE

Please review before attempting install. For more detailed instructions, please refer to included product manual.


PARTS INCLUDED



1 WINDOW KIT



2 ADD'L WINDOW BRACKET



3 AIR EXHAUST HOSE



4 HOSE ADAPTER



5 WINDOW OUTLET



6 WALL FLANGE W/CAP FOR WALL MOUNT



7 ACCESSORY FOR WALL MOUNT

NOT ON ALL MODELS



8 END OF SEASON DUST COVER



9 END OF SEASON ACCESSORIES BAG

EASY SET UP - ALL PARTS INCLUDED - NO TOOLS REQUIRED!

STEP 1



Step 1 - Placement

Select the best window for the air conditioner. The window kit will fit from a 20" to 47" opening. You will need some clearance for the hose and a convenient 3 hole grounded outlet within 5 1/2 feet. Choose a window that is centrally located so it is best positioned to cool the entire room. Do not install in same circuit as other major appliances.

STEP 4



Step 4 - Vent air exhaust hose out window

Insert the window outlet (5) with assembled hose into the oval opening of the installed window kit (1).

STEP 2



Step 2 - Window kit

Take the window kit (1) and install in selected window. If there is still window area exposed, add the additional window bracket (2) to fill the space.

STEP 5



Step 5 - Plug the unit in

Be sure it is a 3 hole grounded outlet within 5 1/2 feet of air conditioner.

STEP 3



Step 3 - Hose assembly

A - Screw hose adapter (4) to air exhaust hose (3)
B - Screw window outlet (5) to the other end of the air exhaust hose (3)
C - Attach the hose adapter (4) with assembled hose to the back of the air conditioner.

STEP 6



Step 6 - Turn unit on and set to your desired temperature.

See reverse for control panel operations.

STEP 7




Step 7 - Storage

Store the cover, product manual and quick set-up guide in a safe place for end of season storage. **(Not on all models)**

For best performance, ensure that air exhaust hose is as close to the window as possible without kinks or bends in the hose that could block air flow and reduce cooling performance.

IMPORTANT NOTES TO PREVENT LEAKING: 1) Make sure air conditioner is on a level surface to prevent any condensate leakage. 2) Before you move the unit, unplug the unit from the wall, and drain any condensation from the drain valve located on the back of the unit into container. If you are in an especially humid region, you should do this regularly to prevent potential leaking. Make sure drain cap is back on tightly.



A	ON/OFF	L	MODE FAN INDICATOR
B	AC/DEHUM/FAN/ HEAT	M	TROUBLE SHOOT INDICATOR
C	TEMP/TIME/LESS	N	FAN SPEED INDICATOR
D	TIMER	O	TEMP INDICATOR
E	FAN SPEED/LOW-MED-HI	P	TIME INDICATOR
F	TEMP/TIME/MORE	Q	SET TEMP/ROOM TEMP/PROGRAMMED ON-OFF TIME
G	MODE AC INDICATOR	R	TIMER SYMBOL
H	MODE DEHUM INDICATOR	S	ROOM TEMP SYMBOL
I	MODE HEAT INDICATOR (Not on all models)	T	SET TEMP SYMBOL

For additional questions or comments, please call our Customer Service Hotline at 1-800-322-3848 (Toll Free – U.S. Only)
www.delonghiusa.com

DeLonghi