

LIMITLESS™

10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports

Quick Start Guide



WHAT'S INCLUDED

- (1) 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports
- (1) Type-C to Micro Charging Adapter
- (1) 36in Type-C to USB Charging Cable
- (1) Microfiber Carrying Pouch with Drawstring




COMPONENTS

10,000mAh Power Bank:

1. Battery Level Display
2. Quick-Charge Icon
3. Type-C to Micro Adapter
4. Built-In Type-C Cable
5. Built-In Lightning® Cable
6. Type-C Charging Port (Input/Output)
7. Mini Flashlight
8. USB Charging Port (Output)
9. Flashlight Power Button
10. Magnetic Contact Pins

Detachable Wall Charger:

11. Detachable Wall Charger
12. Power Indicator Light
13. Type-C Charging Port (Output)
14. Contact Pin Receptacle
15. Retractable AC Plug



GETTING STARTED

This versatile Power Bank features a Detachable Wall Charger that allows you to power your devices wherever you are. Use it as a portable Power Bank on-the-go, a Wall Charger when plugged into an outlet, or both together for seamless charging at home or while traveling.

The Detachable Wall Charger base also doubles as a charging dock for the Power Bank—simply attach the Power Bank to the base to recharge it while you power up other devices. This all-in-one design ensures you're always charged and ready, with no need for extra cables or adapters.

CHARGING A DEVICE

Using the Built-In Cables

To charge a device via the Type-C or Lightning® Cable, pull out the cable from its storage slot and connect to a device. Once the device is connected, it will begin charging automatically.

NOTE: The Detachable Wall Charger does not have to be attached for the Power Bank to charge a device. Simply detach the Detachable Wall Charger and use on the go.

Using the Type-C & USB Port

To charge a device via the Type-C or USB Charging Port, connect a compatible cable. Once the device is connected, it will begin charging automatically.




Using the Type-C to Micro Adapter

Locate the Type-C Built-In Cable. Plug the Type-C end directly into the Micro Adapter opening (**directly underneath the Type-C Cable in the cable slot.**)

Pull the Micro Adapter out once connected via Type-C.

Once the Adapter is installed, plug it into the charging port of the device. The device will begin to charge.



Quick-Charge Icon

The green icon on the Battery Level Display indicates that a quick-charge compatible device is connected and charging. Please note, some devices may not trigger the green icon, but they are still able to optimally charge with the Power Bank.

Attaching the Power Bank to the Detachable Wall Charger.

The Power Bank is connected to the Detachable Wall Charger using Magnets and Magnetic Contact Pins. Simply pull the Power Bank away from the Detachable Wall Charger to disconnect and use independently.

To reattach, align the Magnetic Contact Pins with the Receptacle on the Detachable Wall Charger. The Power Bank will magnetically connect to the Detachable Wall Charger.

Note: It can only be reattached in one direction.

Checking the Battery Level

Press the Flashlight Power Button to show the current battery capacity on the Battery Level Display.



Recharging the Power Bank

Use the Detachable Wall Charger by plugging it into a wall outlet and then attach the Power Bank to it as described under **"Attaching the Power Bank to the Detachable Wall Charger."**

Once connected, the Battery Level Display on the Power Bank will illuminate with the current percentage of battery. As the Power Bank Charges, the capacity will continuously blink until the Power Bank is fully charged and the capacity is 100%.

OR

Use the included Type-C Charging Cable and any USB power source (i.e. a wall adapter, computer USB port, car charger, etc. - not included).

Using the Detachable Wall Charger

Detach the Wall Charger from the Power Bank. Extend the AC plug and insert it into a wall outlet. The Power Indicator Light will illuminate once plugged in.

Connect your device using a compatible Type-C Cable and the Type-C Port on the Wall Charger.



FLASHLIGHT

Press and hold the Flashlight Power Button for 2-3 seconds to turn the Flashlight on. Continuously click the Flashlight Power Button to scan through the modes, or press and hold to shut off the Flashlight.

COMPATIBILITY

Type-C: Galaxy S phones: Galaxy S23, S23+, S23 Ultra, S22, S22+, S22 Ultra, S21 5G, S21+ 5G, S21 Ultra 5G, S20 5G, S20+ 5G, S20 Ultra 5G, S10e, S10, S10+, S10 5G, S8, S8+, S9, S9+ | Galaxy Fold phones: Z Fold, Z Fold2, Z Fold3, Z Fold4, Z Flip, Z Flip 5G, Z Flip3 5G, and Z Flip4 | Galaxy Note phones: Note8, Note9, Note10, Note10+, Note10+ 5G, Note 20 5G, and Note20 Ultra 5G | Galaxy A phones: A03s, A10e, A20, A50, A02, A12, A13, A14 5G, A23 5G, A32 5G, A42 5G, A71, A51, A21, A11, A01, A13 5G, A52 5G, A53 5G, and A54 5G | Apple: iPhone 15 and newer, iPads 2018 and newer, AirPods Pro 2nd gen., and AirPods Max.

Lightning®: iPhones: iPhone 5, iPhone 6, iPhone 7, iPhone 8, iPhone X, iPhone 11, iPhone 12, iPhone 13, iPhone 14, and various SE models | iPads: iPad (4th through 9th gen.), iPad mini (1st through 5th gen.), iPad Air (1st through 3rd gen.), 1st and 2nd gen. of the 12.9-inch iPad Pro, and the 10.5 inch iPad Pro | iPods: iPod nano (7th gen.) and iPod touch (5th through 7th gen.) | Apple Accessories: 1st gen. Apple Pencil, 1st gen. AirPods, AirPods Pro, and earlier versions of Apple's Magic Keyboard, Magic Mouse, and Magic Trackpad.

Micro: Cameras, Gaming Controllers, Bluetooth Speakers, MP3 Players, Navigation Systems, and older Android Phones and Tablets.

USB Port: Compatible with any USB rechargeable device.

TECH SPECS

Model: LIM-DTCHPB-XXXX

Battery Capacity: 10,000mAh | 38.5Wh

Recharging Time (From 0%):

Using Built-In AC Plug: 3-4 Hours

Using Type-C Port: 3-4 Hours

AC Input: 100-240V, 50/60Hz, 0.5A

Wall Charger Type-C Output: PD 20W

GaN Technology

Type-C Charging Port Input: 5V $\overline{\text{---}}$ 3A | 9V $\overline{\text{---}}$ 2A | 12V $\overline{\text{---}}$ 1.5A |

PD 18W

Type-C Charging Port Output: 5V $\overline{\text{---}}$ 3A | 9V $\overline{\text{---}}$ 2.2A |

12V $\overline{\text{---}}$ 1.67A | PD 20W

USB Charging Port Output: 5V $\overline{\text{---}}$ 2A | 10W

Built-In Type-C Cable Output: PD 20W

Built-In Lightning[®] Cable Output: QC 18W

Type-C to Micro Adapter Output: 18W

Temperature Range (Operation): 32°-113°F (0°-45°C)

Flashlight: 25 Lumens

Dimensions: 5.98" x 2.83" x 0.98"

Weight: 8.8oz (0.55lb)

SAFETY INFORMATION

By using the Limitless 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports you hereby agree that Limitless Innovations, Inc., an Illinois corporation and its affiliates ("Limitless") shall have no liability for any losses associated with property damage, personal injury or loss of life that are incurred by you or by any third party in connection with or relating in any manner whatsoever to your use of the Limitless 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports. By using the Limitless 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports, you hereby agree at all times to comply fully with all safety warnings, operating instructions and general safety information in this user manual. By using the Limitless 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports, you further agree to hold harmless Limitless, (and Limitless' officers, directors, shareholders and employees) in connection with any losses sustained by you (including, without limitation, losses arising in whole or in part from property damage, personal injury or loss of life) relating in any manner whatsoever to your use of the Limitless 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports.

WARNINGS

- The 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports is **NOT** a toy and should be kept away from children.
- Do **NOT** use the 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports near a magnetic or electric field.
- Keep the 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports in a cool and dry place away from heat sources, moisture, and dust. Avoid leaving the device in places with high temperatures such as cars parked under the sun.
- Do **NOT** use the 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports if it has been damaged and/or modified.
- Do **NOT** submerge the 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports or its accessories in water.
- Do **NOT** insert any foreign objects into the Type-C or USB output port or joining terminals of the device. Short circuits may present risks of excessive heat, fire or explosion.
- Be cautious of drops, bumps, abrasions, or other impacts to the 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports. If there is any damage to the device such as dents, punctures, tears, deformities, or corrosion due to any cause, discontinue use. Contact Limitless Innovations or dispose of it in accordance to state and local guidelines.
- **CAUTION:** Risk of fire and burns. Do **NOT** open, crush, heat above 140° F (60° C) or incinerate.
- Do **NOT** attempt to charge the 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports using any method, apparatus, or connection other than the device's input port or AC Plug.
- If the 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports has not been used for periods of time, you should charge and discharge it once every three months.
- When charging a device, the 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports may feel warm, this is a normal operating condition and should not be cause for concern.
- All products have gone through a thorough quality assurance inspection. If you find that your 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports is excessively hot, is emitting odor, is deformed, abraded, cut, or is experiencing or demonstrating an abnormal phenomenon, immediately stop all product use and contact Limitless Innovations.
- Do **NOT** attempt to replace the battery as it is a non-serviceable part.
- Do **NOT** subject the 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports to harsh chemicals.
- Do **NOT** paint or apply coatings to the 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports as you might affect moving parts or damage internal components.
- Batteries should be recycled or disposed of, as per state and local guidelines.

AIR TRAVEL

- **You may carry the 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports on an airplane.**
- Do **NOT** travel with the 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports in your checked baggage.

For more information, visit:

<https://www.faa.gov/hazmat/packsafe#hazardousMaterial>

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Scan to learn more about using the features 10,000mAh Power Bank & Detachable AC Wall Charger with Built-In Cables & Ports



LIMITLESS™

Designed in USA. Made in China. All rights reserved. Limitless™ is a trademark of Limitless Innovations, Inc. Design and specifications subject to change without notice. Products may vary from images shown. All other trademarks included herein are property of their respective owners. Accessories sold separately.

LimitlessInnovations.com
Support@LimitlessInnovations.com
(855) 843-4828

© **Limitless Innovations, Inc.**



@LimitlessInnovations



/LimitlessInnov



/LimitlessInnov



/LimitlessInnov



Limitless Innovations