



CALISTA®

FAUXBLO

THERMAL BRUSH

GET STARTED NOW. **BE BEAUTYBRAVE.**

GETTING STARTED

Read all instructions before using.

Use FAUXblo on dry hair only.

1. Plug unit into wall outlet.
2. Hold Power Button for 1-5 seconds until you hear the FAUXblo powering on and Indicator Light turns blue.
3. Power Light will begin to blink blue and continue blinking until it turns solid, which indicates the tool is completely heated, approx: 1-2 minutes.
4. You will hear a double beep when the tool is completely heated and ready to use.
5. Style hair. Keep reading to see how to create versatile looks.
6. When finished using, hold the Power Button for 1-5 seconds or until you hear the FAUXblo powering off and you see the Power Light and Indicator Light turn off.
7. Unplug appliance and allow to cool.

For more tips go to www.youtube.com/calistatools



COOL TIP
Cool-to-touch when unit is heated to allow you to hold tip of brush to ease styling.

STRATEGICALLY PLACED TEETH
Dual rows of softly tipped teeth create a no-tangle experience.

NO-TANGLE BRISTLES
1000 heat resistant and tangle-free bristles offer the perfect tension for easy styling.

FUSION TECHNOLOGY
Combines Ionic Generator and Ceramic Heated Barrel to create damage-free volume, frizz-free smoothness, and healthy shine.

INDICATOR LIGHT
Solid blue light that indicates tool is on.

POWER LIGHT
Ring of blue light around Power Button blinks to indicate tool is heating and turns solid when tool is completely heated.

POWER BUTTON
Turns unit on and off. Heats to 365° F in under 3 minutes.

HOW TO



- FOR LIFT & VOLUME**
1. Take a 2" wide by 1" thick section.
 2. Over direct the section by firmly holding ends of hair up and over the parted section.
 3. With glove on, place FAUXblo underneath the section of hair close to scalp.
 4. Next, brush out to ends and roll back in close to the scalp.
 5. Hold for 5-10 seconds.
 6. Gently roll out and repeat on all sections.



- FOR SMOOTH & STRAIGHT**
1. Take a 2" wide by 1" thick section.
 2. Firmly hold ends of hair with your hand that is wearing the glove to create tension.
 3. Place FAUXblo at the root and slowly glide down section.
 4. Glide straight down for total smoothness, or slightly roll brush inward or outward and hold for 5-10 seconds to create a flip.
 5. Repeat on all sections.



- FOR A CLASSIC BLOWOUT**
1. Take a 2" wide by 1" thick section.
 2. With glove on, hold the brush vertically to your head starting close to root and glide 1" down section while rotating away from face 180°.
 3. Hold for 5 seconds and then continue down section slowly while continuously turning brush.
 4. Repeat until you get to the ends of your hair.
 5. Repeat on all sections.

SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including:

DANGER — As with most electrical appliances, electrical parts are electrically live even when the switch is off:

READ ALL INSTRUCTIONS BEFORE USING. KEEP AWAY FROM WATER TO REDUCE THE RISK OF SERIOUS INJURY BY ELECTRIC SHOCK

1. Always unplug the appliance immediately after using.
2. Do not use while bathing.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in or drop into water or other liquid.
5. If an appliance falls into water, unplug it immediately. Do not reach into the water.

WARNING- To reduce the risk of burns, electrocution, fire, or injury to persons:

1. An appliance should never be left unattended when plugged in.
2. Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
3. Use this appliance only for its intended use as described in this manual.
4. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water. Return appliance to an authorized service center for examination and repair.
5. Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
6. Do not use an extension cord with this appliance.
7. Never use while sleeping.
8. The FAUXblo is hot when in use. Do not let eyes and bare skin touch heated surfaces.
9. Do not use the appliance with any voltage converter.
10. Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
11. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
12. Do not place this appliance directly on any surface while it is hot or plugged in.

IMPORTANT SAFEGUARD

1. The appliance is not intended for unattended use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge.
2. Children should be supervised to ensure that they do not play with the appliance.
3. If the supply cord is damaged, it must be replaced by manufacturer, authorized service agent or similarly qualified persons in order to avoid a hazard.



WARNING: Do not use this appliance near water. Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

IMPORTANT SAFETY FEATURE

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

SERVICING OF DOUBLE-INSULATED APPLIANCES

The FAUXblo is a double-insulated appliance, with two systems of insulation instead of grounding. Grounding is not incorporated on a double-insulated appliance, and grounding should not be added to the appliance. Servicing a double-insulated appliance requires extreme care and knowledge of the system and should be done only by qualified service personnel. Replacement parts for a double-insulated appliance must be identical to the parts they replace. A double insulated appliance is marked with the words "DOUBLE INSULATION" or "DOUBLE INSULATED." The symbol (square within a square) may also be marked on the appliance.

FOR CALIFORNIA RESIDENTS



WARNING: This product can expose you to Bisphenol A, which is known to the State of California to cause cancer and/or birth defects or other reproductive harm. For more information go to www.P65Warnings.co.gov.

ONE-YEAR LIMITED WARRANTY

Our limited warranty program covers your appliance against defects in material or workmanship for 12 months from the date of purchase. This warranty does not cover:

1. Damages caused by misuse, negligence, tampering or alteration of the appliance.
2. Normal wear and tear such as shorts in the power supply cord or plug.
3. Dropping the appliance.
4. Incorrect voltage supply.
5. Damage to cord.
6. Attempted repair by an unauthorized party.
7. Failure to follow safety, operation or maintenance instructions.
8. If used in a commercial or institutional setting.

The warranty extends only to the original purchaser and is not transferable.

Repair or replacement of the product (or if repair or replacement is not feasible, a refund of the purchase price) is the exclusive remedy of the consumer under this warranty. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Any implied warranties, obligations, or liabilities, including but not limited to the implied warranty of merchantability and fitness for particular purposes, shall be limited warranty. In no event shall Calista Tools, LLC be liable for any special, incidental or consequential damages for the breach of this or any other warranty expressed or implied whatsoever.

****All returns must include the product, proof of purchase and a check or money order made payable to Calista Tools, LLC for \$15.00 to cover shipping and handling****

All returns must include the following information:

Name, Address, Phone#, Email Address,
Describe defect

Send postage paid to the following address:

Calista Tools, LLC Attn: Returns
600 Willowbrook Lane - Suite 615
West Chester, PA 19382

Calista Tools, LLC is not responsible for missing or stolen items or appliances that are lost in transit to Calista Tools, LLC. It is strongly recommended that you track your shipment using FedEx, UPS or Registered Mail and keeping the tracking numbers. You are responsible for the shipping charges to send your appliance to Calista Tools, LLC.

PRODUCTS WITH PURPOSE. TOOLS THAT TRANSFORM. BEAUTY FOR ALL.

At Calista, we want you to have the confidence to really see yourself and be brave enough to love what you see.

We create hair products and tools meant to transform not just the way you look, but the way you feel. Calista means "most beautiful" and we want women to discover and embrace their own most beautiful selves.

We believe beauty is defined solely by you. Be #BEAUTYBRAVE.

Share your BeautyBrave stories with us on instagram @CALISTATOOLS

Learn more at WWW.CALISTATOOLS.COM

We can't wait to be inspired by you!

Go Ahead... Be BeautyBrave!

Maria

Founder of The BeautyBrave

Read all instructions before using.

©2022 Distributed by Calista Tools, LLC - West Chester, PA 19382

Contact Calista at CustomerCare@calistatools.com



CALISTA

FAUXblo IB booklet 10_20_21