

PAIRING YOUR REMOTE CONTROL TO YOUR TREADMILL



For first time use or after replacing the battery, point the remote control at the **Control Panel (A)** of the treadmill.



Press and hold the remote control's **Power Button (B)** for 5-8 seconds until the screen displays "3, 2, 1". This will pair the remote control with the treadmill.