



## Instruction Manual

### Wreath with Glistening Lights--50L Battery Operated with Timer

Your item has been carefully packaged for transit, however due to the nature of the materials used; some debris may appear in the bottom of the packaging or while unpacking. We have designed this item so its beauty will not be diminished by the debris.

#### **Included:**

- One (1) Wreath Battery Operated 50 LED – 3D batteries (not included) with timer, twinkle & glistening functions.

#### **Installation Instructions:**

1. Carefully remove wreath from packaging.
2. **Shape Wreath - “Due to the natural transit of this item, we have found that the wreath may flatten during packaging and need to be fluffed. Please know that this can be remedied by manually shaping the wreath to your desired look.”**
3. Open the battery box cover insert 3D batteries (not included). Follow diagram in battery box for proper orientation. (Do not mix old and new batteries; do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries).
4. Close battery box cover.
5. Set battery box switch to desired mode:
  - On – Steady: lights are on constantly.
  - On – Twinkle: lights are on constantly with twinkling effect.
  - On – Glisten: lights are on constantly with glistening effect.
  - Timer –Steady: The lights will stay lit for 6 hours and then switch off for 18 hours. The lights will turn on every day at the same time as originally set and stay on for 6 hours each time. \* For example: If you want the lights to turn on every day at 5pm you need to turn the power switch to timer at 5pm. Lights will turn on every day at 5pm and stay lit until 11pm.
  - Timer-Twinkle: The lights will stay lit with twinkling effect for 6 hours and then switch off for 18 hours. The lights will turn on every day at the same time as originally set and stay on for 6 hours each time. \* For example: If you want the lights to turn on every day at 5pm you need to turn the power switch to timer at 5pm. The lights will then turn on every day at 5pm and stay lit until 11pm.
  - Timer-Glisten: The lights will stay lit with glistening effect for 6 hours and then switch off for 18 hours. The lights will turn on every day at the same time as originally set and stay on for 6 hours each time. \* For example: If you want the lights to turn on every day at 5pm you need to turn the power switch to timer at 5pm. The lights will then turn on every day at 5pm and stay lit until 11pm.
  - Off – lights are off.
6. Place in desired location.

#### **Care Instructions:**

If lights or product becomes dusty or dirty, clean with a dry cloth. Do not use detergent as it may discolor the product.

- If lights start to go dim, replace batteries. Please note these are LED lights and they are not replaceable.
- Remove batteries before storing.
- Store in cool dry location



**Battery Information and Disposal:**

- Do not dispose batteries in fire.
- For best results, do not mix old and new batteries; do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries).
- For best results, use alkaline batteries
- Install only new batteries of the same type in your product.
- Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
- Improper handling/disposal of batteries may cause batteries to explode or leak. Please dispose of batteries responsibly by throwing away batteries in a proper trash receptacle.
- Batteries should be recycled or disposed of as per state and local guidelines.

**FCC Information:**

Model: **BOLED-0504545-D**, manufactured by **Chane Hua Electrical Manufacturing Factory**. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference Received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.