

Battery Operated Window Candle

Features:

Dual intensity bent LED technology.

Point bright side of candle outward toward the window

Adjustable Height

Adjust height to avoid mullion bars on windows

Built in daily 6 hour timer

No need to turn candle on and off daily

Replaceable LED Bulb and Bulb Cover


Assembly:

1. Unscrew bulb
2. Insert 4 x AA batteries (+ side up)
3. Replace bulb.
 - a. Candle will turn on once the bulb is fully screwed in.
 - b. Timer is set when candle is turned on. Candle will stay lit for 6 hours, turn off, and turn back on at the same time every day.
 - c. To reset daily timer, unscrew bulb and screw back in at desired start time.

Height Adjustment: Candle height has two positions.

Shorter:

1. Remove candle taper from base
2. Remove rubber ring from bottom of candle




3. Slide candle taper into base.
4. Store rubber ring on bottom of the base.



Taller:

1. Remove rubber ring from candle base
2. Remove candle taper from base
3. Replace rubber ring on bottom of candle




4. Place candle in top of base so rubber ring is seated in top of the base



Bulb Cover Replacement:

Should you break the glass cover of the LED bulb it can be replaced



Remove glass bulb envelope (be careful if there is broken glass)
Release the bulb cover by holding the ribbed plastic rim and
unsnapping (vs twisting if you were unscrewing)
Put on new glass envelope
Push in new glass envelope onto the base until it clips in
(Make sure match the “Tooth” and “Channel” , or the
tooth will be broken.)

Care:

- Remove batteries when not in use
- Replace batteries when candle dims
- Dispose of used batteries responsibly
- Clean with non abrasive cleaner

Batteries should be recycled or disposed of per state
and local guidelines

Made in China