


INSTRUCTIONS

90" LED Spider Web




In the Box:

- 1x Folding Web (and power cord)
- 1x Front Bar
- 1x Rear T-Bar
- 1x Remote (battery included)
- 4x Ground Stakes

Parts:
1x Folding Web


1



Loosen rear nut to the top of its threads. Lay web flat on the ground. Expand the branches.

Parts:
1x Folding Web


2



Twist outer metal ring slightly to block branches from folding. Flip web over and tighten the nut.

Parts:
1x Front Bar
1x Rear T-Bar


3



Orient support legs downward. Insert front and rear support bars. Expand legs to connect T-bar to the front.

Parts:
4x Ground Stakes (optional)


4



Insert safety pins at each connection. Adjust sliding nut to angle the web. For outdoor use, insert ground stakes.



Remove plastic from battery compartment before first use



Remote Operations:

On/ Off – Lighting power
Cycle – Auto-cycles through each function
4H/ 6H/ 8H Timer – Press and hold, the lights flash once and remain on for the time selected. Lights then turn off until 24h after timer was started. Repeats daily. Timer is not affected by changing functions. To cancel, power on and off manually.

Functions:

- (Spider lights **Purple**)
1. Steady **Warm White**
 2. Steady **Orange**
 3. Flash **Warm White**
 4. Flash **Orange**
 5. Color Morph **Warm White to Orange**

Battery Use & Disposal

1. Use a CR2025 Lithium Battery.
2. Only install new batteries.
3. Battery polarity is marked on the battery compartment. Installing with incorrect polarity may shorten life or cause a leak.
4. Do not dispose of batteries in fire.

The CR2025 battery is considered hazardous waste and is to be disposed of properly at a local hazardous waste collection site for proper handling. Ensure the item holds no charge when disposing. Depending on your waste service provider, you may recycle your battery. Please check with your provider and local and state guidelines.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could deny the users authority to operate the equipment.
NOTE: This equipment has been a tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it can cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular situation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Re-orient or relocate the receiving device (wall plug); Increase the separation between the equipment and receiver; Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

Charm Christmas Trees US LLC, 1155 Phoenixville Pike, Suite 105 West Chester PA 19380, 1-833-386-0080
 Made in China
 Printed in China
 This is not a toy, for decorative use only