

Instructions

Flag Assembly:

- Loosen set screw from one fastener and slide fastener up from bottom of pole to just below the ornament. The spinning snap-hook should be facing up towards the top of the pole when the pole is upright.
- Hand-tighten the set screw.
- Clip the snap hook to the top grommet of your flag.
- Loosen set screw from the second fastener and slide fastener up from bottom of pole to a point where it is parallel to the lower grommet of your flag. This second spinning snap hook should be facing down towards the bottom of the pole when the pole is upright.
- Hand-tighten the set screw.
- Clip the snap hook to the lower grommet of your flag.
- Adjust the fasteners so that there is no slack in the heading of the flag but do not make the heading too taut or else the flag will not spin.

To Mount Bracket & Pole:

- Mount bracket to flat surface with screws supplied and tightly secure.
- Insert pole into the bracket at a 45° angle for flag-style display or at 90° for banner-style display.

Flag Care:

Machine wash in cold water, lay flat or hang to dry. Do not fold when wet.

