



Troubleshooting:

If over time Adjustment Point 1 becomes loose due to algae. Add any type of tape to the back side of the water spray nozzle. This will help keep water spray nozzle in position.



Step 1: Simply unsnap Water Spray Nozzle from housing.

Step 2: Add any type of tape to back side of Water Spray Nozzle.

Step 3: Snap Water Spray Nozzle back into Housing.