

METAL[®] GARDEN HOSE

PRO SERIES

www.berninifountains.com

INSTRUCTIONS:


1. Remove the Metal Garden Hose[®] from the package and completely unravel your Metal Garden Hose[®].
2. Attach the spray nozzle (included) to the **outlet** of the Metal Garden Hose[®] (figure 1). Make sure 1 rubber washer is in place.
3. Attach the Metal Garden Hose[®] **inlet** to the water supply of your home (figure 1). Make sure 1 rubber washer is in place.
4. Turn on the faucet from your home's water supply to the Metal Garden Hose[®].

NOZZLE CLEANING: (DO NOT DISASSEMBLE WHILE PRESSURIZED)

The Metal Garden Hose[®] Pro Series Aluminium Nozzle is designed to be disassembled and cleaned should your nozzle become clogged.

1. Hold the inlet of the nozzle and turn spray adjuster counter clockwise to unscrew from base.
2. Rinse or wipe any debris from nozzle internals (careful of o-rings).
3. Dry with clean towel or cloth.
4. Reassemble nozzle, by screwing spray adjuster clockwise until spray adjuster comes to a stop. This is the off position, do not overtighten.

① Assemble hose to faucet




MGHI00179_03 rev10c

② Storing your hose

You can store your Metal Garden Hose[®] on just about any common hose reel or simply coil your hose next to your faucet.

TIP: When you are finished watering with your Metal Garden Hose[®] It's best to release the water pressure from your hose before storing.



⚠ WARNING

- This product can expose you to chemicals including lead, cadmium, and phthalate which is [are] known to the State of California to cause cancer or birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.
- The water in ANY garden hose may become contaminated and cause serious health effects.
- Strangulation hazard. Hose wrapped around neck may cause serious injury or death.
- Keep out of reach of children.
- For general OUTDOOR use ONLY in applications under 80 psi.
- DO NOT use this hose for commercial applications, in hot water applications, or high pressure applications. Doing so may cause serious personal injury and or damage or destroy the product. However you can use it on the low pressure inlet side of a high pressure washer.
- DO NOT leave this product unattended when it is in use or under pressure.
- This product is NOT A TOY.

LIMITED ONE YEAR WARRANTY

For warranty information please refer to our website at: berninifountains.com/warrantyinfo.html. Call us for assistance at: +1 (619) 449-2392 or you can email or mail us at: 9545 Pathway Street, Santee, CA 92071 customer@berninifountains.com Our Customer Care Department is available: Monday - Friday 8:30am to 4:00pm PST / 11:30am - 7:00pm EST



LIMITATION OF LIABILITY

Liability limited to the purchase price of this product. YRD LLC shall not be liable for any incidental or consequential damages or any implied warranty on this product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

2019 © Yeiser Research & Development and Metal Garden Hose[®]. Trade names, product names, patterns, prints, images and logos used in this document are the trademark or registered trademarks of YRD LLC, Santee, CA 92071

WORLD WIDE PATENTS PENDING