

Stair Tool



Removes dirt and dust from corners and against vertical edges of stairs

Combination Tool



Reaches further and has softer bristles for improved spot cleaning and gentle dusting

Tangle-Free Turbine Tool



Counter-rotating heads with brushes to remove hair and dirt from carpets and upholstery. It's the only turbine tool that doesn't tangle

Multi-Angle Tool



Twists to give multiple angles to help remove dust, dirt and allergens from hard to reach surfaces

Carbon Fiber Soft Dusting Brush



Designed to specifically pick up fine dust -its best used for unit tops, flat screen TV's, window sills, mirrors and any other glass, polished wood

Stiff Bristle Brush



The stiff bristle brush quickly attaches to the wand and helps loosen and clean dried-in and stubborn dirt from carpet, in the home and in the car