




HALO Lantern Flashlight



Operating Instructions



1. Power Button
2. LED Flashlight
3. Adjustable Handle
4. Lantern Light

Included Items

- 1 HALO Lantern Flashlight
- Operating Instructions/Limited Warranty

Getting Started

Unscrew the bottom of your HALO Lantern Flashlight (#2 above) and remove the clear plastic cover protecting the batteries (batteries are included with your HALO Lantern Flashlight).

To Turn On/Off your HALO Lantern Flashlight

Press the black power button found on the side of your HALO Lantern Flashlight to turn the device on. Pressing the black power button three times will turn your HALO Lantern Flashlight off.


Flashlight Modes

Select your desired mode by repeatedly pressing the power button. Mode sequence is as follows- Flashlight, Lantern, and flashing yellow light.

HALO Lantern Flashlight Adjustable Handle Feature

You have three options to use the adjustable handle feature of your HALO Lantern Flashlight.

1. Grab the elastic cord of the flashlight from the side with one hand
2. Unclip the adjustable handle to allow for loose carrying capabilities
3. Clip the elastic cord to the top opposite side of the lantern to carry



Storing/Handling/Cleaning the HALO Lantern Flashlight

- This HALO Lantern Flashlight has been designed and manufactured to ensure personal safety. Please read the following carefully before using:
- Do not get wet or store in extreme temperature conditions.
- Do not disassemble your HALO Lantern Flashlight or attempt to repair it.
- Use a soft cloth with soap to clean the exterior of your HALO

Lantern Flashlight. Do not use liquid detergent or chemicals of any kind.

- Carefully read the operating instructions, and use your HALO Lantern Flashlight correctly and for appropriate uses.

Replacing the Batteries

1. Unscrew the bottom of your HALO Lantern Flashlight. Remove the battery holder and remove the batteries from the battery holder. Old batteries should be recycled or disposed of as per state and local guidelines.
2. Replace the three AA batteries by following the arrow guide on the battery holder and inserting the negative end of the AA battery first.
3. After replacing all three AA batteries, insert the battery holder into the battery chamber, negative end first.
4. Screw on bottom of your HALO Lantern Flashlight.

Limited Warranty

What does this limited warranty cover and how long is the coverage?

Halo2Cloud, LLC ("HALO") warrants its products to be free from defects in materials and workmanship under normal use and service for a period of one (1) year beginning on the date you purchase the product.

What is not covered by this limited warranty?

This Limited Warranty does not cover defects or damage due to: (1) accidents, acts of God, misuse, abuse, abnormal use, abnormal conditions, improper storage, or exposure to liquid or moisture, (2) unusual or abnormal physical force or impact, including dropping of the product, (3) connection of the product to improper voltage supply, or (4) attempted repair or modification by anyone other than HALO or a facility authorized by HALO.

What are HALO's obligations under this limited warranty?

Provided that you comply with the conditions of this Limited Warranty, during the duration of this Limited Warranty HALO will repair or replace the product, at its sole option, without charge. When repairing or replacing a product, HALO may, at its sole option, repair or replace the product with new, used, rebuilt or reconditioned parts or products. HALO will warrant any product that is repaired or replaced under this Limited Warranty for a period equal to the remaining time period under the original Limited Warranty or ninety (90) days, whichever is longer.

How do you get service?

To obtain service under this Limited Warranty, you must (1) within ninety (90) days of the purchase of the product, register you product at www.halo2cloud.com, (2) obtain a return materials authorization number (RMA) by contacting HALO at (888) 907-6274, and (3) return the product to HALO at 148 Eastern Boulevard, Glastonbury, Connecticut 06033, Attention: Returns Department, together with your RMA and the sales receipt or similar proof of sale showing the original date of purchase of the product and the seller's name and address. If HALO determines that your product is not covered by this Limited Warranty, HALO will notify you of such determination and you may decide whether to have HALO return the product to you or attempt to repair the product. In this case, you will be required to pay all shipping and labor charges for the repair or return of your product, as applicable.

What are the limits of HALO's liability?

This Limited Warranty sets forth the full scope of HALO's obligations and liabilities with respect to the product. All implied warranties, including, without limitation, implied warranties of merchantability and fitness for a particular

purpose, are limited to the duration of this Limited Warranty. In no event shall HALO be liable for any incidental, special, consequential or punitive damages or any damages or losses of or to electronic equipment or products that are used with any of HALO's products.

How does state law relate to this limited warranty?

Some states do not allow limitation on how long an implied warranty lasts or the disclaimer or limitation of incidental or consequential damages. Therefore, some or all of the disclaimers and limitations above may not apply to you.

To contact us, email us at
support@halo2cloud.com
or call 888-907-6274

HALO2CLOUD, LLC
148 Eastern Boulevard
Glastonbury, CT 06033 USA
www.halo2cloud.com

The HALO cloud logo is
a registered trademark of
HALO2CLOUD, LLC

Designed in USA

Made in China