






Instructions for extending your Wisp® Handle



1. To extend your Wisp® Handle, loosen the Lower Handle by turning *counter-clockwise*.




2. Pull out to extend and then turn the Lower Handle *clockwise* to tighten.




3. To loosen the Middle Handle turn it *counter-clockwise*. Pull out Middle Handle then turn *clockwise* to tighten.




Instructions for extending your Wisp® Handle



1. To extend your Wisp® Handle, loosen the Lower Handle by turning *counter-clockwise*.



2. Pull out to extend and then turn the Lower Handle *clockwise* to tighten.



3. To loosen the Middle Handle turn it *counter-clockwise*. Pull out Middle Handle then turn *clockwise* to tighten.