

Assembly Instructions:

1. Your Touch lamp is able to be assembled in two different height configurations. Short or Tall. The Lamp comes pre-assembled in the Short configuration with Rod (B) pre-attached to Lamp Base (C).
2. To make Lamp taller, remove Lamp Base (C). Connect top of Rod (D) larger threaded end to bottom of Rod (B). Hand Tighten. Connect bottom of Rod (D) to Base (C). Hand Tighten.

Touch Table Lamp Operation:

1. To turn lamp ON or OFF, tap Touch Sensor located on top of lamp. Tap once to turn ON, Tap again to turn OFF. (See E)
2. To change the brightness level, With light ON, Hold finger on Touch Sensor until desired brightness is reached. Repeat process to increase or decrease brightness.

How to Recharge Touch Table Lamp

1. Plug the included Touch Table Lamp USB Type-C Cable into any powered USB Port. (See F) Please note, the lamp's USB Port is located underneath the shade (See G)
2. A Red Indication Light will illuminate when charging and will turn green when fully charged. (See H)

Please Note: The Rechargeable Indoor/Outdoor Touch Table Lamp will charge fully in approximately 3 hours. The lamp will illuminate for approximately 40 hours at the lowest setting (24 Lumens), and 4-5 hours at the highest setting. (180 Lumens)

Care:

- Turn off Touch Table Lamp when not in use to save rechargeable battery life.
- Do not attempt to repair the Touch Table Lamp if damaged.
- Clean the Touch Table Lamp as needed with a soft dry cloth.
- Always lift Touch Lamp by the center Rod.

