

Wagner 915e Steamer Frequently Asked Questions



How do you fill it?

Use the included **FUNNEL** and **FILL CUP**. Fill with **DISTILLED WATER**.



How much water does it hold?

40FL OZ. (5 cups)

Do you need distilled water?

You can use tap water, but distilled water is **PREFERRED** for machine longevity for the following reasons:

- Prevents mineral buildup (scaling)
- Protects internal components
- Longer lifespan and fewer repairs



How long does it take to heat up?

UP TO 9 MINUTES for full tank of water.
Please read manual.

How long does the steam last?

Up to **40 MINUTES**.


To change accessories safely:

Accessories are safe to change or remove when you are NOT steaming. Engage the safety lock on the handle and wait 30 seconds before changing.

Refilling or emptying reservoir safely:

SAFETY CAP will rotate but will not unscrew until unit is cool and pressure is released. Once cool the safety cap will open with ease. Please reference the manual for additional information.

Steam Smarter Tips for a cleaner home!



When you first turn on the steamer, the water hasn't fully reached steam temperature. Until it does, the cleaner pushes out a mix of hot water and steam—so you'll often see it spitting water at the start.

Tips for the **BEST** steam experience:

1. Do not overfill reservoir.
2. Wait 9 minutes for water to heat up.
3. After taking a break, make sure to run the steamer over a bucket or sink for 20 seconds to eliminate/clear out condensation.

WAGNER[®]