

LIMITLESS™

Handheld Rechargeable Fan

Quick Start Guide





WHAT'S INCLUDED

- (1) Handheld Rechargeable Fan
- (1) 24" USB to Type-C Charging Cable
- (1) Detachable & Adjustable Neck Strap

COMPONENTS

1. Fan
2. Cooling Plate
3. Digital Display
4. Fan Power Button
5. Cooling Plate Power Button
6. Type-C Charging Port
7. LED Flashlight
8. Retractable AC Plug
9. Detachable Neck Strap Holder
10. Flashlight Power Button
11. Phone Holder / Kickstand
12. Detachable & Adjustable Neck Strap
13. 3x Safety Breakaway Points
14. 2x Strap Attachment Clasps



GETTING STARTED

Charging the Fan

Plug the included cable into the Type-C charging port. Connect the USB end to a power source (not included).

NOTE: If you're using a wall charger, make sure it's a 5V=2A / 10W.

OR

Use the Retractable AC Plug.

NOTE: Rotate the Fan head forward before plugging into a wall outlet. The Digital Display will indicate charging status.

NOTE: The Fan will come with a partial charge. Fully charge to 100% before the first use.

USING THE FAN

Turning the Fan On

Single press the Fan Button once to turn the Fan ON. The screen will briefly display the Fan speed level. After approximately 3 seconds, the screen will automatically switch to show the remaining battery percentage.

Changing the Fan Speed

The Fan has 5x preset speed levels: 1, 25, 50, 75, 100, & OFF.

When the Fan is ON, press the Fan Button once to increase to the next preset fan speed.

Example: If the Fan is currently at 25, pressing the Fan Button once will change the speed to 50.

Double press the Fan Button to turn the Fan OFF immediately without cycling through the speed levels.

NOTE: If you want to increase the Fan Speed without jumping to the next preset level, press and hold the Fan Button to increase the speed (quickly) in increments of 1.

NOTE: If you want to decrease the Fan Speed, press and hold the Cooling Plate Button to decrease the speed (quickly) in increments of 1.

Using the Cooling Plate

With the Fan ON, single press the Cooling Button and place the Cooling Plate against the skin for instant cooling relief. To turn off the Cooling Plate, single press the Cooling Button again.

NOTE: The Cooling function only works when the Fan is ON.

Using the Flashlight

Press the LED Button to turn the Flashlight On. Each single press cycles through the light modes: On, SOS, Strobe, & Off.

Press and hold the LED Button to turn the Flashlight OFF immediately, without cycling through modes.

NOTE: The Flashlight works independently — it can be turned On or Off whether the Fan is running or not.

Using the Phone Holder & Kickstand

The Fan features a fold-out base that rotates into two different positions depending on how far it is turned.



Kickstand

Phone Holder

Kickstand Feature

When the base is rotated 90 degrees or less, it acts as a Kickstand to support the Fan upright on a flat surface.

Phone Holder Feature

When the base is rotated fully forward to the front of the Fan, it acts as a Phone Holder with a front ledge to support your smartphone in landscape orientation while cooling.

NOTE: Always use on a flat, stable surface. Avoid uneven surfaces or edges where the Fan or phone could tip over.

Adjustable Fan Head Tilt

The Fan head can be tilted front-to-back to direct airflow upward or downward. Hold the Fan body firmly and gently adjust the head to your desired angle.

NOTE: Adjust the Fan head slowly and do **NOT** apply excessive force. Do **NOT** attempt to twist or rotate the Fan head sideways, as this may damage the internal mechanism.



USING THE NECK STRAP

This Neck Strap includes 3x Safety Breakaway Points designed to release under tension to help prevent injury if the strap becomes caught or pulled.

How to Attach the Neck Strap

Locate the Strap Holder on each side of the Fan. Open the two Clasps on the Strap, and clip one Clasp onto each Holder on the fan until secure.

NOTE: Make sure all 3x Safety Breakaway Points are fully snapped closed before use.

WARNING: Do **NOT** swing the Fan from the strap. The Safety Breakaway Points may detached, and the fan can fly away and cause injury or property damage.

Wearing the Fan

Place the Strap over your head so the Fan rests at the center of your chest.

Adjust the Strap length using the slider so the Fan sits comfortably at upper-chest or collarbone height.

The Fan head is tiltable. Gently tilt the Fan head upward or downward so the airflow is directed toward your: neck, face or upper chest area.

TECH SPECS

Model: LIM-HHF-XXX

Battery Capacity: 4,000mAh | 14.8Wh

Recharging Time (From 0%):

Using Built-In AC Plug: 3-4 Hours

Using Type-C Charging Cable: 3-4 Hours

AC Input: 10W

Type-C Built-In Port: 5V = 2A | 10W

Fan Run-Time: Up to 3-4 Hours Depending on Fan Speed and if the Cooling Plate is on.

LED Flashlight: 50 Lumens | High, S.O.S. & Strobe

Fan RPM: Up to 8,200 Depending on Fan Speed and if the Cooling Plate is on.

100x Speeds: 5x Preset Levels | 1, 25, 50, 75, & 100

Temperature Range (Operation):

32°-113°F (0°-45°C)

Cooling Plate Temperature (Operation): 59°F +/- (15°C +/-)

Dimensions: 7.99" x 2.28" x 1.97"

Weight: 0.55 lbs

WAIVER & RELEASE

By using the Limitless Handheld Rechargeable Fan, you hereby agree that Limitless Innovations, Inc., an Illinois corporation and its affiliates ("Limitless") shall have no liability for any losses associated with property damage, personal injury or loss of life that are incurred by you or by any third party in connection with or relating in any manner whatsoever to your use of the Limitless Handheld Rechargeable Fan. By using the Limitless Handheld Rechargeable Fan, you hereby agree at all times to comply fully with all safety warnings, operating instructions and general safety information in this user manual. By using the Limitless Handheld Rechargeable Fan, you further agree to hold harmless Limitless, (and Limitless' officers, directors, shareholders and employees) in connection with any losses sustained by you (including, without limitation, losses arising in whole or in part from property damage, personal injury or loss of life) relating in any manner whatsoever to your use of the Limitless Handheld Rechargeable Fan.

WARNINGS

- The Handheld Rechargeable Fan is **NOT** a toy and should be kept away from children.
- Do **NOT** insert fingers or objects into the Handheld Rechargeable Fan.
- Do **NOT** use the Handheld Rechargeable Fan near a magnetic or electric field.
- Keep the Handheld Rechargeable Fan in a cool and dry place away from heat sources, moisture, and dust. Avoid leaving the device in places with high temperatures such as cars parked under the sun.
- Do **NOT** use the Handheld Rechargeable Fan if it has been damaged and/or modified.
- Do **NOT** submerge the Handheld Rechargeable Fan or its accessories in water.
- Do **NOT** insert any foreign objects into the Type-C Port or joining terminals of the device. Short circuits may present risks of excessive heat, fire or explosion.
- Be cautious of drops, bumps, abrasions, or other impacts to the Handheld Rechargeable Fan. If there is any damage to the device such as dents, punctures, tears, deformities, or corrosion due to any cause, discontinue use. Contact Limitless Innovations or dispose of it in accordance to state and local guidelines.
- Do **NOT** attempt to disassemble, repair, or open the Handheld Rechargeable Fan or its accessories in any way.
- **CAUTION:** Risk of fire and burns. Do **NOT** open, crush, heat above 140° F (60° C) or incinerate.
- Do **NOT** use at an altitude higher than 6,562 feet (2,000 meters).
- Do **NOT** subject the Handheld Rechargeable Fan to harsh chemicals.

WARNINGS

- If the Handheld Rechargeable Fan is not used for long periods of time, you should charge and discharge once every three months.
- All products have gone through a thorough quality assurance inspection. If you find that your Handheld Rechargeable Fan is excessively hot, is emitting odor, is deformed, abraded, cut, or is experiencing or demonstrating an abnormal phenomenon, immediately stop all product use and contact Limitless Innovations.
- Batteries should be recycled or disposed of, as per state and local guidelines. Do **NOT** throw in the trash, as this can create a fire hazard.
- Do **NOT** apply excessive force on the Handheld Rechargeable Fan or drop it: By doing so, it may damage the internal components of the device, and risk short circuiting the device when used.
- Do **NOT** overcharge the Handheld Rechargeable Fan as this may cause it to overheat and deplete efficiency. If the device becomes excessively hot during charging or discharging, unplug it from the power source or device immediately.
- Do **NOT** attempt to replace the battery as it is a non-serviceable part.
- Always ensure all 3x Safety Breakaway Points on the Neck Strap are properly closed before wearing.
- Do **NOT** tie, knot, glue, or modify the Neck Strap or Breakaway components.
- The Neck Strap is equipped with 3x Safety Breakaway Points that are designed to separate automatically if the Strap is pulled or caught on an object. This feature is intended to help reduce the risk of choking, entanglement, or injury.

- Do **NOT** wear the Neck Strap while sleeping or during activities where the strap could become caught (sports, machinery, playground equipment, etc.).
- Keep the Neck Strap and Fan away from children and pets when not in use.
- Do **NOT** swing the fan from the strap. The Safety Breakaway Points may detached, and the Handheld Rechargeable Fan can fly away and cause injury or property damage.

AIR TRAVEL

- **You MAY carry the Handheld Rechargeable Fan on an airplane.**
- Do **NOT** travel with the Handheld Rechargeable Fan in your checked baggage.

For more information, visit:

<https://www.faa.gov/hazmat/packsafe#hazardousMaterial>

Scan to learn more about using the features of your Handheld Rechargeable Fan



LIMITLESS™

Designed in USA. Made in China. All rights reserved. Limitless™ is a trademark of Limitless Innovations, Inc. Design and specifications subject to change without notice. Products may vary from images shown. All other trademarks included herein are property of their respective owners. Accessories sold separately.

LimitlessInnovations.com

Support@LimitlessInnovations.com
(855) 843-4828

© **Limitless Innovations, Inc.**



@LimitlessInnovations



/LimitlessInnov



/LimitlessInnov



/LimitlessInnov



Limitless Innovations