

Basic Directions

1. Turn on unit:

Hold  button for about 3 seconds, unit start heating and LCD blinks until setting temperature reached. It will take about 3 minutes. (Default temperature setting: 365°F)



2. Temperature adjust:

Press "+" or "-" button to desired temperature.

Press "+" or "-" button one time, the temperature setting will increase or decrease 10°F

Temperature range: 325°F-395°F

LCD will keep blinking until setting temperature is reached.

Once you adjust temperature setting level it will take about 3 minutes.

Basic Directions (cont.)

3. Lock function:

Press  button twice within 3 seconds, temperature adjust function will be locked.
A lock mark will appear on the LCD (Fig 1)



Fig 1

Press  button twice within 3 seconds again, temperature adjust function will be unlocked. Lock mark will disappear from the LCD (Fig 2)



Fig 2

4. Shut off:

Hold  button for about 3 seconds, unit will be shut off.

5. Unit will shut off automatically after 1 hour.