

Cleaning

Regular cleaning and good maintenance ensures optimum results and will extend the lifetime of your **Emjoi® eRase™ Pro e60**.

1. Before cleaning, make sure to turn off your unit and if you have it plugged in, unplug it from the electrical outlet.
2. Remove the epilator head by pressing the release button on the front of the unit.
3. Remove the disc cover by squeezing both sides of the disc cover and pulling the tweezer head up.

4. Using the brush, enclosed, remove hair on all sides of the discs.
5. Place the tweezer head into the disc cover by gently pressing until it clicks into place.
6. Place the epilator head back onto the unit until it clicks into its place, by lining up the toothed wheel on the body and the epilator head.
7. Put the protective cap on to safeguard the tweezers.

To Remove Residue:

To remove residue from the tweezers, use rubbing alcohol on the tip of the tweezers with a cotton swab that has been squeezed dry.

Note: Make sure that the cotton swab is not soaked with alcohol.