

Emjoi®  
eRase™  
Pro e60



Close Up Of  
Emjoi® eRase™ Pro e60



Sensitive Cover

Electrically-operated

# Emjoi® eRase™ Pro e60

**Before using your Emjoi® eRase™ Pro e60, please read all these instructions carefully and completely.**

The **Emjoi® eRase™ Pro e60** is an amazing hair remover with 60 tweezer action discs to ensure rapid hair removal from the root for weeks. With Precision Hair Removal Technology removing hair from the root has never been easier or more comfortable. Dual opposed heads stretch the skin to make the process comfortable and the sensitive cover hides some of the tweezers and is great in sensitive areas.

**When using an epilator for the first time we suggest that you test the unit on an area that has light hair growth in order to get accustomed to the epilation process.**

## **Caution**

Do not store or use your **Emjoi® eRase™ Pro e60** where it can fall into a tub or sink of water. Do not reach for your unit if it has fallen into water, immediately unplug it.

## **Caution**

Before plugging into an electrical outlet, make sure that the adapter is appropriate for the local voltage. This is extremely important when traveling overseas.



## Instructions for use

For best results: Take a warm bath or shower, to open up your pores, and use a loofa or exfoliation cream in small circles to exfoliate and remove dead skin from the area you wish to remove hair. Doing this before you use your **Emjoi® eRase™ Pro e60** will cleanse and make your skin pliable, so removing hair will be less uncomfortable.

1. Use your **Emjoi® eRase™ Pro e60** in a location that has a comfortable temperature to avoid perspiration.
2. Make sure that the areas you wish to remove hair from are clean, dry and free from moisturizing cream or oil.
3. Insert the adapter plug into the bottom of the unit.
4. Plug your adapter into an electrical outlet.
5. Remove the protective cap, by gently pulling, from your **Emjoi® eRase™ Pro e60**.
6. To turn On your unit, press the safety switch lock and at the same time slide it up to the desired speed. Low is recommended for fine hair and high is recommended for coarse hair.
  - 0 Power "OFF"
  - I Low speed
  - II High speed
7. Hold the unit in your palm, at a 90° angle, so the Emjoi® logo is facing you.
8. Position your **Emjoi® eRase™ Pro e60** so that the discs are upright the Emjoi® logo should be facing you.
9. Hold the skin **taut** surrounding the area you are removing hair from.
10. Gently glide the **Emjoi® eRase™ Pro e60** in short, quick, brush like or sweeping strokes in the direction of hair growth.

**Note:** For your protection, your **Emjoi® eRase™ Pro e60** may slow down, or stop operating completely if it is pressed too hard against the skin
11. Before removing hair from the bikini line and underarms it is important to use a loofa or exfoliation cream in a warm shower or bath to remove dead skin and prevent ingrown hair. If it has been an extended amount of time since you have removed hair from your bikini line and underarms, trim the hair with a scissor or trimmer. Make sure to hold your skin taut with one hand while removing hair.

12. When using on the face the **Emjoi® eRase™ Pro e60** is only intended to remove **individual** hair from the upper lip and chin but you must hold the unit so only **one** of the epilation heads is parallel with the skin. Do not use both of the epilation heads on the face. Hold area taut and use a small brushing motion. **Do not use like an electric shaver on your entire face!**
13. Repeat within each area until all unwanted hair is removed. The time required to remove unwanted hair depends on the user's hair type.
14. After each use clean your **Emjoi® eRase™ Pro e60**.
15. Keep the protective cap on your unit when it is not in use.

### Using The Sensitive Cover

The sensitive cover makes removing hair in sensitive areas more comfortable.

1. Remove the protective cap.
2. Place the sensitive cover over the head of the unit.
3. The sensitive cover hides some of the tweezers to make it more comfortable in sensitive areas like the upper lip, underarms and bikini line.
4. Hold the area taut and use a small brushing motion to remove unwanted hair.
5. Repeat within each area until all unwanted hair is removed.
6. Remove the sensitive cover and place the protective cap on the unit when it is not in use.

### Cleaning

Regular cleaning and good maintenance ensures optimum results and will extend the lifetime of your **Emjoi® eRase™ Pro e60**.

1. Before cleaning, make sure to turn off your unit and if you have it plugged in, unplug it from the electrical outlet.
2. Remove the epilator head by pressing the release button on the front of the unit.
3. Remove the disc cover by squeezing both sides of the disc cover and pulling the tweezer head up.

4. Using the brush, enclosed, remove hair on all sides of the discs.
5. Place the tweezer head into the disc cover by gently pressing until it clicks into place.
6. Place the epilator head back onto the unit until it clicks into its place, by lining up the teathed wheel on the body and the epilator head.
7. Put the protective cap on to safeguard the tweezers.

**To Remove Residue:**

To remove residue from the tweezers, use rubbing alcohol on the tip of the tweezers with a cotton swab that has been squeezed dry.

**Note:** Make sure that the cotton swab is not soaked with alcohol.

## Warning/Important

- Before using your hair remover please read all these instructions carefully and completely.
- Use the **Emjoi® eRase™ Pro e60** only for purposes described in this instruction book.
- Please keep these instructions for future reference.
- This unit is intended for one person. We discourage sharing the unit with others.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- **Warning** - To reduce the risk of burns, fires or electric shock, never leave your **Emjoi® eRase™ Pro e60** unattended when plugged in.
- Household use only.
- Do not use an extension cord with this unit.
- Keep the appliance dry.
- This unit is for dry use only.
- Do not place or store the unit in direct sunlight. Please store your unit in a cool dry place at a temperature between 0 - 40°C.
- Do not store your unit where it can fall into a tub or sink of water.
- **Warning** - Do not use your **Emjoi® eRase™ Pro e60** while bathing or in the shower. Your **Emjoi® eRase™ Pro e60** is not waterproof or water resistant and is not intended to be used near water, in the bathtub or in the shower.
- Do not place your unit in water or drop water into your unit.
- Do not reach for your unit if it has fallen into water. Immediately unplug the unit.
- Place the adapter into the unit and then into the electrical outlet. Make sure that the plug is inserted firmly into the appliance. When you are finished using your unit turn the unit "OFF" and then remove the adapter from the electrical outlet and then from the unit.

- When you unplug your unit please pull on the plug and not on the cord.
- Always unplug your unit when it is not in use and before cleaning it.
- Do not wrap the cord of your adapter around the unit.
- Keep the cord of the adapter away from hot surfaces.
- Never use your unit if the adapter cord or electrical outlet is damaged.
- Do not cut off the adapter to use it with another plug as this can be a hazardous situation.
- Only use your **Emjoi® eRase™ Pro e60** with the adapter supplied with the unit. For questions regarding your adapter in the US contact 1-888-99EMJOI, M-F, 9-5 EST.
- **Caution:** Before plugging into an electrical outlet, make sure that the adapter is appropriate for the local voltage. This is extremely important when traveling overseas.
- Do not use this unit if the epilation head is damaged as this could lead to injury.
- Never use your unit if it has been damaged or dropped into water.
- Do not use your unit if it has damaged or broken tweezer discs as injury may occur.
- Do not drop or insert anything into any openings of the unit.
- Do not use your unit outdoors.
- Do not use your unit where aerosol products or oxygen is being used.
- Children should be supervised to ensure that they do not play with this appliance.
- Keep your unit out of reach of children.
- This appliance is not to be used on, by or near children or invalids.
- Only use this unit on clean, dry, lotion free skin.
- Do not use water or any other liquid on the tweezers other than rubbing alcohol.
- **To prevent accidents and injury to you or damage to the unit** - when your **Emjoi® eRase™ Pro e60** is in use, keep it away from the hair on your scalp, your eyebrows, eyelashes as well as clothes, brushes, wires, cords, shoelaces etc.

- Do not use the **Emjoi® eRase™ Pro e60** if you have – allergic or sensitive skin that reacts to cosmetics, metals, clothing, etc., acne, body acne, warts, around moles and loose skin, diabetes, Raynaud’s disease, eczema, psoriasis, hemophilia, immune deficiency, rosacea, couperose, varicose veins, wounds or when your skin has rashes or is sunburned, inflamed or irritated. Consult with your health care provider prior to use if you have any of the above conditions.
- Do not use the unit before or during menstruation, during pregnancy or for one month after giving birth unless you consult with your health care provider prior to use.
- Changes in your hormone levels (taking hormone medication, recently pregnant) can influence the color or thickness of hair growth. These changes are not caused by this product but hormonal changes.
- If you have any medical conditions, issues, questions or any sensitivity whatsoever we strongly advise you to consult with your health care provider before using this product.
- If you have a pacemaker consult with your health care provider prior to use.
- If you are epilating for the first time, we recommend doing it in the evening so any possible redness or irritation can go away overnight. We suggest testing the unit gradually over a period of two to three days to allow your skin to adjust.
- If you have never epilated before (or if it has been an extended time since you epilated) you will feel a prickling sensation when using the unit. This feeling is due to the fact that you are removing hair from the root. After a few sessions the sensation you feel should diminish.
- Removing hair from the root can cause ingrown hair and skin irritation (redness of the skin, discomfort, itching). If you know that you are prone to ingrown hair, removing hair from the root may not be for you. Regular skin massaging with a massaging glove or loofa, may help reduce the chance or occurrence of ingrown hair. After using the epilator you can use body cream or aloe vera to sooth the skin and any possible irritation.

- Using an epilator may cause redness or irritation of the skin. This is a normal reaction that will quickly disappear, but may be longer if you have very sensitive skin or are removing hair from the root for the first few times. If any irritation remains for more than 3 days, discontinue use and consult with your health care provider.
- Sometimes inflammation of the skin can occur when bacteria penetrates the skin. Cleaning the epilation head before and after each use can minimize the risk of infection.
- When using on the face the **Emjoi® eRase™ Pro e60** is only intended to remove **individual** hair from the upper lip and chin but you must hold the unit so only **one** of the epilation heads is parallel with the skin. Do not use both of the epilation heads on the face. Hold area taut and use a small brushing motion. **The Emjoi® eRase™ Pro e60 is NOT an electric shaver and should NOT be used like an electric shaver on your entire face!** Using the **Emjoi® eRase™ Pro e60** like an electric shaver, without holding the skin taut, could potentially allow the **Emjoi® eRase™ Pro e60** to pinch or grab the skin, which could potentially cause irritation and skin damage.
- Before removing hair from the bikini line and underarms it is important to use a loofa sponge or exfoliation cream in a warm shower or bath to remove dead skin and help minimize the chance or occurrence of ingrown hair. If it has been an extended amount of time since you have removed hair from your bikini line and underarms (if the hair is longer than 5mm), trim the hair with a scissor or trimmer. Make sure to hold your skin taut with one hand while removing hair. Some women may experience irritation after removing hair from the underarms and bikini line for the first time. We suggest testing the unit on a small part of the skin in these areas first.
- Do not continually rub the unit on the same area or apply strong pressure.
- Keep the protective cap on your unit when it is not in use.

## Frequently asked questions

Q : Does the **Emjoi® eRase™ Pro e60** hurt?

A : The first time you use the **Emjoi® eRase™ Pro e60** you might feel a prickling sensation, this feeling is due to the fact that you are removing hair from the root. After several uses, the tweezing becomes more comfortable even for those with sensitive skin.

Q : How should I hold the **Emjoi® eRase™ Pro e60** ?

A : To minimize discomfort, hold the skin surrounding the area you are removing hair from taut. Gently glide, do not apply pressure, the **Emjoi® eRase™ Pro e60** in short, quick, brush like or sweeping strokes in the direction of hair growth.

**Note:** For your protection, your **Emjoi® eRase™ Pro e60** may slow down, or stop operating completely if it is pressed too hard against the skin.

Q : Do I have to use my **Emjoi® eRase™ Pro e60** with the adapter?

A : Yes. Your unit is electrically-operated and always needs to be plugged into the electrical outlet when in use.

Q : Can I use the **Emjoi® eRase™ Pro e60** on my upper lip?

A : Yes, the **Emjoi® eRase™ Pro e60** can be used to remove **individual** hair from the upper lip and chin but you must hold the unit so only **one** of the epilation heads is parallel with the skin. Do not use both of the epilation heads on the face. You can also place the sensitive cover onto the head of the unit. This will hide some of the tweezers to make it more comfortable in sensitive areas. Hold area taut and use a small brushing motion.

Q : Can I use the **Emjoi® eRase™ Pro e60** anywhere on my face?

A : No. When using on the face the **Emjoi® eRase™ Pro e60** is only intended to remove **individual** hair from the **upper lip** and **chin** but you must hold the unit so only **one** of the epilation heads is parallel with the skin. Do not use both of the epilation heads on the face. When removing hair from your upper lip and chin, hold skin taut and use short brushing motions. Do not use the **Emjoi® eRase™ Pro e60** like you would an electric razor on your entire face.



Q : Can I use the **Emjoi® eRase™ Pro e60** on my bikini line and underarm ?

A : Yes. Before removing hair from the bikini line or underarms it is important to use a loofa sponge in a warm shower or bath to remove dead skin and prevent ingrown hair. Since these areas can be sensitive, it is important to hold the skin taut.

Q : Will my hair grow back as fast as it does when I shave?

A : No. With shaving, you are cutting the hair at the surface, so hair grows back quickly. When you use the **Emjoi® eRase™ Pro e60** it removes hair from the root so it takes longer, to grow back.

Q : What if my skin becomes red after using the **Emjoi® eRase™ Pro e60**?

A : Whenever you remove hair from the root your skin may become red or irritated. To sooth irritations you can use lotion.

Q : What can I do for ingrown hair?

A : We recommend using a loofa or an exfoliation cream in the shower or bath to soften the skin and any ingrown hair, enabling the **Emjoi® eRase™ Pro e60** to remove the hair from the root, if any irritation remains for more than 3 days, discontinue use and consult with your health care provider

Q : I have varicose veins, can I use the **Emjoi® eRase™ Pro e60** ?

A : Regarding any medical issues or questions, we strongly advise you to consult with your health care provider prior to use.

Q : Do I have to clean the **Emjoi® eRase™ Pro e60** ?


A : Yes. We recommend that you clean your unit after each use. Before cleaning make sure to turn off your unit and if it is plugged in, unplug it from the electrical outlet. Remove the disc cover by squeezing both sides of the disc cover and pulling the tweezer head up. Using the brush, enclosed, remove hair on all sides of the discs. Place the tweezer head into the disc cover by gently pressing until it clicks into place.

Q : Should I let someone else use my **Emjoi® eRase™ Pro e60** ?

A : No. For sanitary reasons, the **Emjoi® eRase™ Pro e60** is only recommended to be used by one person.



# Parts Description/Accessories Name




## Instructions for use


For best results take a warm bath or shower and use a loofa or exfoliation cream, in small circles to remove dead skin and open pores. Doing this before you use your **Emjoi® eRase™ Pro e60** will help to make the hair removal process more comfortable.



Insert plug into base of unit.




Place the adapter into socket.



For sensitive areas add the Sensitive Cover to the head of the unit. This will hide some of the tweezers to make it more comfortable in sensitive areas like the bikini line, upper lip and underarms.




May be used for the bikini area (hold the skin taut with one hand).



3

Remove the plastic protective cover.



4


To turn On the unit, press the safety switch lock and at the same time slide it up to the desired speed.

The unit has 2 speeds:

0 Power "OFF"


I Low speed for fine hair

II High speed for coarse hair




11

Can be used to remove **individual** hair on the upper lip and chin but you must hold the unit so only **one** of the epilation heads is parallel with the skin. Do not use both of the epilation heads on the face.




12

May be used to remove hair from underarms (extend your arm so skin is stretched taut).




**5**

Close up for eRase Tweezer Head




**6**

Hold the unit in your palm, at a 90° angle, so the Emjoi® logo is facing you. Do not apply pressure; just glide the unit over the surface of the skin.




**13**

Gently brush the tweezers to remove any hair.



Hold the skin taut and move the unit in short, quick, brush like, back and forth motions or sweeping motions in the direction of hair growth. Do not apply heavy pressure; just move the unit back and forth over the surface of the skin. After each movement, lift the unit from the skin to move to a new section. The 60 tweezer head is not a shaver so you cannot go from your ankle to your knee in one motion. Work in small sections until the hair is removed and then move up to the next section until all the unwanted hair is removed.



Take extra care to extend the leg before removing hair from behind the knee.

## **Warranty**

The **Emjoi® eRase™ Pro e60** warranty against defects in material and workmanship lasts one year from the date of purchase.

### **Keep original receipt for warranty service.**

During this warranty period, return the product to Emjoi, Inc. with proof of purchase to FDR Station, PO Box 7406, New York, NY 10150. Emjoi will take care of repair, or at their discretion, replacement of a defective unit without charge. For questions regarding this policy you may call toll free 1-888-99-EMJOI (1-888-993-6564).

**Important:** This warranty does not cover damages resulting from accidents, misuse, alterations, abuse, lack of reasonable care, or performance of services or repairs by an unauthorized service center. The manufacturers and distributors of the **Emjoi® eRase™ Pro e60** do not assume responsibility for any damage caused by misuse or use other than that described in these instructions.

Model No. AP-14AGY, AP-14APC, AP-14AHP, AP-14APP, AP-14AWT

US Patent No. 5,976,157

Other patents issued and pending

Made in China

© Soft Lines International Ltd. 2015