



1. Protective Cover
2. Micro-Smooth (Gray) roller for smoothing - mounted on the unit
3. Micro - Shine (White) roller for shining - enclosed
4. Safety Switch Lock
5. On/Off Switch
6. Release button for battery cover - bottom of unit

