

CLEANING

The **Emjoi® Micro-Pedi Nano Pro** should be cleaned after each use. It is not water resistant so do not submerge the unit in to water as it may cause defects to the unit.

1. Turn the unit off.
2. Remove the protective cover and the Micro-Pedi Nano Pro Micro-Mineral roller from the unit.
3. Use the cleaning brush to remove any debris from the head of the unit.
4. Use the cleaning brush to remove any debris from the Extra Coarse (Blue) Micro-Mineral roller. **Micro-Pedi Extra Coarse (Blue) Micro-Mineral rollers should not be placed in water.**
5. The Extreme Coarse Flex (Purple) Micro-Mineral roller can be cleaned with the brush or rinsed under running water. Rinse the Extreme Coarse Flex (Purple) Micro-Mineral roller under running water for 2-3 seconds (do not submerge in water) and let the roller air dry. Do not use hair dryer to dry the roller it needs to be dried naturally.
6. Wipe the body with a clean dry cloth.
7. Replace the Micro-Pedi Micro-Mineral roller and protective cover.