

# USING THE MICRO-PEDI MANICURE ATTACHMENTS

The Micro-Pedi Manicure roller contains fragile parts, please handle them with care.

Please take extra care when replacing the Micro-Pedi Manicure roller.

Make sure the unit is turned off before replacing the Micro-Pedi Manicure roller.






1. Pull down the release button, on the side of the unit, while the end cap is facing up and the Micro-Pedi roller will pop out (fig. 24 & 25).

2. After the Micro-Pedi roller pops out, remove it from the cylinder holding the end cap of the Micro-Pedi roller (fig. 26).

3. Place the Manicure roller holder into the unit (make sure the hole is facing out) until it clicks into place (fig. 27).

4. After placing the Manicure roller holder into the unit check that it has been firmly installed with no signs of shaky or loose parts (fig. 28 & 29).

5. Insert any of the nail attachments in the Manicure roller holder (fig. 30 & 31). Be sure to insert the thinner side of the attachment firmly into the opening on the roller holder.



Precision /  
Manicure Roller Holder



## 1. Buffing Tool

Buff the nail surface back and forth, careful not to over buff which may cause redness and soreness



## 2. Emery Tool

File the nail to the desired shape either square or rounded



## 3. Shaping Tool

Smooth the nail surface prior to buffing



## 4. Fine Shaping Tool

For a more precise shape and to contour the nails



## 5. Cuticle Tool

Use to push the cuticles back to keep them neat and clean