


Instructions for use

For ultimate results take a warm bath or shower and use a loofa or exfoliation cream, in small circles to remove dead skin and open pores. Doing this before you use your **Emjoi® eRase™ e60** will help to make the hair removal process more comfortable.




1 Insert plug into base of unit.



2 Place the adapter into socket.




3 Remove the plastic protective cover.




4 To turn On the unit, press the safety switch lock (raised button with 3 dots) and at the same time slide it up to the desired speed.

The unit has 2 speeds:

- 0 Power "OFF"
- I Low speed for fine hair
- II High speed for coarse hair



5 Close up for eRase Tweezer Head



6 Hold the unit in your palm, at a 90° angle, so the Emjoi® logo is facing you. Do not apply pressure; just glide the unit over the surface of the skin.



7 Use back and forth motion (short/quick) in the direction of hair growth. After each movement, lift the unit from the skin to move to a new section. It is not a shaver so you cannot go from your ankle to your knee in one motion. Work in small sections.



8 Take extra care to extend the leg before removing hair from behind the knee.



9 For sensitive areas add the Sensitive Cover to the head of the unit. This will hide some of the tweezers to make it more comfortable in sensitive areas like the bikini line, upper lip and underarms.




10 May be used for the bikini area (hold the skin taut with one hand).



11 On the face, the Emjoi® eRase™ e60 is only intended for use on the upper lip, chin and jaw line. You must hold the unit so only **one** of the epilation heads is touching the skin. Do not use both of the epilation heads on the upper lip, chin and jaw line. For added comfort you can use the sensitive cover (see Using The Sensitive Cover).



12 May be used to remove hair from underarms (extend your arm so skin is stretched taut).



13 Gently brush the tweezers to remove any hair.