

CHARGING

Your device is rechargeable with the included charging base. A fully charged device provides approximately 28 minutes of use depending on the setting at which it is run. The convenient USB-enabled charger is provided to recharge the device using either a traditional wall mount AC adapter or computer USB port.

Charging Indicators

Action	Indicator
Place device on charger	Device emits two pulses.
Charge the device	The battery life indicator will flash from red to green as it charges.
When fully charged	Battery life indicator glows solid green. Allow 18 hours for a full charge.



The charger is compatible with 100–240 Volts AC; 50/60 Hz, allowing it to be used worldwide with the appropriate country adapter. If the shape of the plug does not fit the power outlet, use an attachment plug adapter of the proper configuration for the power outlet.

NOTE:

- This device is not compatible with other Clarisonic charger models.
- Do not use charger on metal surfaces, as it will interfere with proper device charging.