

CLEANING

The **Emjoi® Micro Mani™** should be cleaned by using a towel or tissue after each use. It is not water resistant so do not submerge the unit into water as it may cause defects to the unit. **Micro Mani™ rollers should not be placed in water.**

1. Make sure the unit is turned off.
2. Remove the protective cover and the Micro Mani™ roller from the unit.
3. Use a towel or tissue to remove any debris from the roller and head of the unit.
Note: Micro Mani™ rollers should not be placed in water.
4. Wipe the body with a clean dry cloth.
5. Replace the Micro Mani™ roller and protective cover.