

Care

BE SURE TO UNPLUG THE PERFECTER
AND CARE AFTER IT COOLS DOWN.

For cleaning the Perfecter barrel, use the Calista Tools Glide™

1. Holding the Glide™ with your thumb and index finger, starting at the bottom of the barrel, place the prongs directly on the barrel between the rows.
2. Move the Glide™ up along the rows
3. Reaching the top of the barrel, lift and pull up the Glide™
4. Remove/dispose of build-up and excess hair
5. Repeat on each row

- *Clean often to avoid collecting dust and hair*
- *Do not rinse with water. It may damage the Perfecter.*

Caution When Storing

BE SURE TO CHECK THE FOLLOWING
BEFORE USING THE PERFECTER.

1. Turn the on/off button off, and unplug.
2. Be sure barrel has cooled off.
3. Do not wrap cord around the Perfecter.

