

Care & Storage

Before cleaning or storing this unit, unplug and allow to cool thoroughly.

- Do not rinse with water. It may damage the **Illustra Beauty** styling brush.
- Do not use cleaning products that contain benzene, paint thinner or harsh, flammable ingredients of any kind. They may damage the **Illustra Beauty** styling brush or present a fire hazard.
- For cleaning the bristles, use cotton swabs.
NOTE: Be cautious not to leave the cotton fibers on the bristles.
- Clean often to avoid collecting dust and hair.

STORING

BE SURE TO CHECK THE FOLLOWING BEFORE STORING.

1. Power Off unit and unplug.
2. Be sure barrel has cooled off.
3. Do not wrap power cord around the **Illustra Beauty** styling brush.