

## Select the Right Heat Setting

Use the chart below to select suggested settings according to your hair type.

<b>SELECT YOUR HAIR TYPE</b>	<b>TEMPERATURE</b>
Coarse or Thick Hair	390°F to 410°F
Wavy or Curly Hair	375°F
Medium Thickness or Straight Hair	355°F
Thin Hair	340°F
Fine Hair	320°F

## Illustra Beauty TIPS

- For best results use unit on clean hair.
- Hair texture and the amount of curl or frizz determines the setting and speed used to straighten hair.
- For thinner less curly hair use a lower temperature setting and a faster brushing technique.
- For thick hair with more frizz and curl a higher temperature setting and slow brushing works best.



## Using Your **Illustra Beauty** Styling Brush

1. Power On The **Illustra Beauty** styling brush and select temperature to match your hair type.  
For proper temperature setting, see chart to the left of this page. Start with the lowest setting for your hair type and increase temperature to a higher setting if needed.
2. Grasp a section of hair from bottom as shown above.
3. Brush hair from top to bottom in a smooth fluid motion.